DECserver 250
Software Installation Guide
(VMS)

Order Number: AA–MH06A–TE

September 1989

This guide explains how to install the DECserver 250 distribution software on VMS systems, how to establish VMS systems as load hosts, and how to verify the installation. This guide is intended for the VMS system manager or the network manager.

Revision/Update Information:	This is a new manual.
Operating System and Version	VMS 4.7 or later.
Software Version:	DECserver 250 V1.0 or later.

Digital Equipment Corporation
Maynard, Massachusetts

AA–MH06A–TE
First Edition, September 1989

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

© Digital Equipment Corporation 1989.

All Rights Reserved.
Printed in U.S.A.

The postpaid Reader's Comments forms at the end of this document request your critical evaluation to assist in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

DEC	DIBOL	UNIBUS
DEC/CMS	EduSystem	VAX
DEC/MMS	IAS	VAXcluster
DECnet	MASSBUS	VMS
DECsystem–10	PDP	VT
DECSYSTEM–20	PDT	
DECUS	RSTS	
DECwriter	RSX	digital™

This document was prepared using VAX DOCUMENT, Version 2.0.

Contents

PREFACE ix

CHAPTER 1 INTRODUCING THE DECserver 250 SERVER FOR PRINTERS 1–1

1.1 WHAT IS THE DECserver 250 SERVER FOR PRINTERS? 1–1

1.2 DECserver 250 CONCEPTS 1–1
1.2.1 Connections 1–1
1.2.2 Services 1–2
1.2.3 Service Nodes and LAT Protocol 1–2
1.2.4 LAT Software 1–2

1.3 PERFORMING THE SOFTWARE INSTALLATION 1–3
1.3.1 Installing the DECserver 250 Distribution Software 1–4
1.3.2 Required VMS Tailoring Class 1–5
1.3.3 Configuring the Load Host's Node Database 1–5
1.3.4 Verifying the Installation 1–6
1.3.4.1 Verifying the Load Host Installation • 1–7
1.3.4.2 Verifying the Server System Installation • 1–7

CHAPTER 2 INSTALLING THE DECserver 250 DISTRIBUTION SOFTWARE 2–1

2.1 OVERVIEW OF VMSINSTAL 2–1

2.2 PREPARING TO RUN THE INSTALLATION PROCEDURE 2–1

2.3 VMSINSTAL CONVENTIONS 2–2

2.4 RUNNING VMSINSTAL 2–2

2.5 SPECIAL INSTALLATION CONSIDERATIONS FOR DSVCONFIG.COM 2–10

2.6 INSTALLING ONTO ALTERNATE LOAD HOSTS 2–10
2.6.1 Installing onto Single Systems 2–11
2.6.2 Installing onto VAXclusters 2–12
2.6.3 Installing onto Other Operating Systems 2–12

2.7 AFTER EXITING VMSINSTAL 2–12

CHAPTER 3 CONFIGURING THE LOAD HOST'S NODE DATABASE 3–1

3.1 OVERVIEW OF DSVCONFIG 3–2
3.1.1 Databases Affected by DSVCONFIG 3–3
3.1.2 DSVCONFIG Options for the Software Installer 3–3

3.2 SPECIFYING DECNET CHARACTERISTICS DURING DSVCONFIG 3–4
3.2.1 DECnet Node Name 3–5
3.2.2 DECnet Node Address 3–5
3.2.3 Ethernet Address 3–5
3.2.4 Server Type 3–6
3.2.5 Load File (Server Image File) 3–6
3.2.6 Dump File Name 3–6
3.2.7 Service Circuit 3–6

3.3 PREPARING TO RUN THE CONFIGURATION PROCEDURE 3–8

3.4 DSVCONFIG CONVENTIONS AND REQUIREMENTS 3–9

3.5 RUNNING DSVCONFIG 3–10
3.5.1 List Known DECservers (Option 1) 3–12
3.5.2 Add a DECserver (Option 2) 3–13
3.5.3 Restore Existing DECservers (Option 5) 3–15

3.6 RESTORING WITH THE RESTORE PARAMETER AND FROM YOUR START-UP PROCEDURE 3–15

3.7 CONFIGURING ON VAXCLUSTER NODES 3–16
3.7.1 Running DSVCONFIG for the First Time 3–16
3.7.2 Running This Version of DSVCONFIG Again 3–18

3.8 EXITING DSVCONFIG 3–18

3.9 AFTER EXITING DSVCONFIG 3–18

CHAPTER 4 VERIFYING THE INSTALLATION 4–1

4.1 VERIFYING THE LOAD HOST INSTALLATION 4–1
4.1.1 If You Are Loading a New Server 4–2
4.1.2 If You Are Loading an Existing Server 4–2
4.1.2.1 Loading During Off-Hours • 4–2
4.1.3 Down-Line Loading with the LOAD Command 4–3
4.1.3.1 Preparing for the LOAD Command • 4–3
4.1.3.2 Issuing the LOAD Command • 4–4
4.1.3.3 Using DECnet Event Logging • 4–5

4.2 VERIFYING THE SERVER SYSTEM INSTALLATION 4–5

4.3 DETERMINING AND REPORTING PROBLEMS 4–8

APPENDIX A DECserver 250 DISTRIBUTION FILES A–1

APPENDIX B USING THE REMOTE CONSOLE FACILITY B–1

APPENDIX C EXAMPLES: INSTALLATION, CONFIGURATION, VERIFICATION C–1

C.1 EXAMPLE OF AN INSTALLATION C–1

C.2 EXAMPLE OF A CONFIGURATION: STARTING DSVCONFIG.COM C–4

C.3 EXAMPLE OF A CONFIGURATION: THE DSVCONFIG.COM MENU C–4

C.4 EXAMPLE OF A CONFIGURATION: LISTING KNOWN DECservers (OPTION #1) C–5

C.5 EXAMPLE OF A CONFIGURATION: ADDING A DECserver (OPTION #2) C–5

C.6 EXAMPLE OF A CONFIGURATION: SWAPPING AN OLD UNIT FOR A NEW UNIT (OPTION #3) C–6

C.7 EXAMPLE OF A CONFIGURATION: DELETING A DECserver FROM THE DATABASE (OPTION #4) C–6

C.8 EXAMPLE OF A CONFIGURATION: RESTORING EXISTING DECservers TO THE DATABASE (OPTION #5) C–7

C.9 EXAMPLE OF VERIFICATION: VERIFYING A LOAD HOST INSTALLATION C–7
C.9.1 Using RCF and Warning Server Users C–7
C.9.2 Enabling DECnet Event Logging and Checking Server Names C–8
C.9.3 Down-Line Loading with the LOAD Command C–9
C.9.4 DECnet Event-Logging Display after Issuing LOAD C–9
C.9.5 Conclusion of a Load Host Installation Verification C–9

C.10 EXAMPLE OF VERIFICATION: VERIFYING THE SERVER SYSTEM INSTALLATION C–9

APPENDIX D HOW TO ORDER DOCUMENTS D–1

D.1 INTRODUCTION D–1

D.2 ORDER NUMBERS D–1
D.2.1 VMS Software Documentation Kit D–1
D.2.2 ULTRIX-32 Software Documentation Kit D–2
D.2.3 TSM Documentation Kit D–2
D.2.4 Hardware Documents D–2

D.3 ORDERING PROCEDURES FOR CUSTOMERS D–2

D.4 ORDERING PROCEDURES FOR DIGITAL EMPLOYEES D–3
D.4.1 Software Documentation Kits D–3
D.4.2 Hardware Manuals D–4

INDEX

TABLES

D–1 Hardware Documents D–2
D–2 How to Order By Telephone D–3
D–3 How to Order By Mail D–3

Preface

This installation guide explains how to:

- Install the DECserver 250 distribution software onto a VAX/VMS system running DECnet Phase IV so that this system can then perform as a load host. The potential load host can be a single system or a member node of a VAXcluster.
- Configure the load host's node database.
- Verify the installation by first down-line loading the server image to the DECserver 250 unit and then testing a few server commands.

Intended Audience

This guide is for system managers or network managers who are responsible for making server products available on Ethernet. A system manager is responsible for the VAX/VMS system that is about to be established as a load host. A network manager is the person responsible for the Local Area Network (LAN).

To use this guide effectively, you should be familiar with both DECnet Phase IV network management concepts and the VAX/VMS operating system.

Structure of This Manual

This manual has four chapters and four appendices:

Chapter 1	Introduces the DECserver 250 product and summarizes the installation, configuration, and verification procedures.
Chapter 2	Explains how to prepare for the installation, and then how to install the distribution software.
Chapter 3	Explains how to configure the load host's node database.
Chapter 4	Explains how to verify the installation by first down-line loading the server image and then testing a few server commands.
Appendix A	Lists the names of the files in the DECserver 250 distribution kit.
Appendix B	Discusses briefly the Remote Console Facility (RCF).
Appendix C	Contains examples of the installation and configuration procedures, and examples of verification by down-line loading.
Appendix D	Contains information on how to order additional documents.

Other DECserver 250 Documents

- *DECserver 250 Management Guide*

  Describes all the initial and day-to-day management tasks required of the DECserver 250 manager. This guide covers the information needed to configure the ports and customize the permanent and operational databases of the server. This guide is intended for the DECserver 250 manager.

- *Terminal Server User's Reference Card*

  Describes the most frequently used server commands. This card is intended for users of an interactive terminal that is connected to port 1.

- *DECserver 250 Hardware Installation/Owner's Guide*

  Describes environmental requirements for the DECserver 250 unit and the installation of the hardware unit. This guide is intended for the hardware installer.

- *DECserver 250 Identification Card*

  Provides the space to record identification information for the DECserver 250 unit. This document is intended for the network manager, the software installer, and the server manager.

- *Terminal Server Commands and Messages Reference*

  Describes the usage and syntax of all server commands (privileged and nonprivileged). This guide also lists and describes all status and error messages used by the server. This reference is intended for the server manager.

- *DECserver 250 Commands Mini-Reference*

  Summarizes all privileged and nonprivileged server commands and characteristics in a pocket-size mini-reference. This reference is intended as a memory jog of command syntaxes for both privileged and nonprivileged users.

- *DECserver 250 Problem Determination Guide*

  Describes the server's troubleshooting tools and procedures. It explains how to isolate server faults to the field replaceable unit level. This guide is intended for the server manager.

- *DECserver 200 Rackmount Option Installation Guide*
  Tells you how to install the rackmount assembly for the DECserver 200/250 unit.

DECserver 250 On-Line Documentation

- *DECserver 250 Release Notes*
  Covers any discrepancies between the actual product and the information in the documentation set. These notes are intended for the software installer and the server manager.
- *On-Line Help*
  Provides two forms of server help: tutorial help and command reference help. Tutorial help provides basic information about logging in and using the server. Command reference help provides detailed information about using all the server commands available to the user. DECserver 250 on-line help is intended for all server users.

Associated Documents

- *LAT Network Concepts Guide*
  Presents information about LAT and LAT networks. It discusses LAT concepts and definitions, and provides guidelines to coordinate the configuration, performance, and troubleshooting of LAT servers and service nodes.
- *DECnet–VAX Network Management Concepts and Procedures*
  Explains DECnet Phase IV and how to run it.
- *Guide to Networking on VAX/VMS*
  Discusses the Network Control Program (NCP).
- *VAX/VMS Network Control Program Reference Manual*
  Talks about DECnet event logging.

- *VAX/VMS System Messages and Recovery Procedures Reference Manual*

  Explains all NCP information and error messages.

- *Guide to Terminal Server Manager*

  and

  Terminal Server Manager Software Installation Guide

  Explains how to install and run the Terminal Server Manager (TSM) software (V1.3-01), an optional network management product, which is installed onto a VAX/VMS system running DECnet–VAX. These guides describe how to use TSM to manage a mix of Digital Equipment Corporation Ethernet terminal servers connected to the same Ethernet as a VAX computer. These guides are intended for the installer and manager of the TSM software product.

  NOTE

  If you have the TSM software, read the documentation for this product before you look at the DECserver 250 documents. TSM affects the way you install and manage servers.

Conventions Used in This Manual

Familiarizing yourself with the conventions discussed in this section will help you use this manual effectively. The following conventions apply to numbers:

- All numbers are decimal unless otherwise noted.
- All Ethernet addresses are given in hexadecimal.

Graphic Conventions Used in This Manual

Convention	Meaning
`Special type`	This special type in examples indicates system output or user input.
`Red type`	Red type in examples indicates user input.
UPPERCASE	Uppercase letters in command lines indicate keywords that must be entered. You can enter them in either uppercase or lowercase. You can abbreviate command keywords to the first three characters or the minimum unique abbreviation.
lowercase italics	Lowercase italics in command syntax or examples indicate variables for which either the user or the system supplies a value.
[ ]	Square brackets in command lines indicate that the enclosed values are optional. In the installation dialog, square brackets enclose default answers. To choose the default, press the RETURN key. To specify another value, type the answer after the question and press the RETURN key. In either case, do not type the brackets.
BOLD	Bold text identifies an important term that is defined in the text.
KEY	Press the specified key. For example, RET indicates that you press the RETURN key.
CTRL/*X*	Hold down the CONTROL key and then press the key specified by *x*. Pressing <CTRL> displays the ^ character.

1 Introducing the DECserver 250 Server for Printers

1.1 What Is the DECserver 250 Server for Printers?

The DECserver 250 server for printers is a hardware and software product that connects to an Ethernet Local Area Network (LAN). The server connects two parallel printer ports, three asynchronous serial printer ports, and one asynchronous port (for either a terminal or serial printer that is a console device) to a LAN, allowing only the console device to communicate as a terminal with the other nodes on that LAN.

The software that you are about to install consists of the files in the DECserver 250 distribution kit. After installing the distribution software onto your VAX/VMS system, configure your system's node database for all new servers. Next, verify the installation by down-line loading one test server. **Down-line loading** means sending the server image from the established load host to the server. Finally, issue a few server commands to test the server system. The rest of this chapter describes DECserver 250 features and concepts and gives an overview of your responsibilities as the software installer.

1.2 DECserver 250 Concepts

The DECserver 250 unit gives printer access to all services of the LAN, supporting direct connections.

1.2.1 Connections

The DECserver 250 unit connects the following devices:

- Two parallel printers
- Three serial printers
- One terminal - port 1 only

Port devices can be connected directly to the server or, on port 1, they can be connected remotely by using a modem. The DECserver 250 unit supports printers and connections to hosts that support parallel, asynchronous, and RS-232-C connections.

1.2.2 Services

The DECserver 250 unit gives printers access to services offered on the LAN. A **service** is a resource such as a computer. A DECserver 250 user on port 1 can maintain up to six simultaneous connections to these various services.

1.2.3 Service Nodes and LAT Protocol

Server users are offered services by service nodes. A service node is any node on the LAN that implements the Local Area Transport (LAT) protocol. The server, in turn, uses the same LAT protocol to connect printers to these services. LAT architecture uses Ethernet to make logical connections between printers and service nodes on the same network.

When connected to a service, a printer appears to be connected directly to the service node. DECnet is not necessary for VAX/VMS systems to function as LAT service nodes. The DECserver 250 unit itself can be configured as a service node, offering either a printer, one dial-out modem, or a console terminal on port 1.

1.2.4 LAT Software

LAT V5.1 or later is implemented on VAX/VMS nodes. This includes the LTDRIVER, which is a port driver in direct communication with the system's terminal class driver. LTDRIVER implements the protocol necessary to communicate with devices connected to the server and is used in place of a local port driver, such as the DZDRIVER. A LAT Control Program (LATCP) provides the command interface to the LTDRIVER. LATCP can be used to start and stop the driver as well as to set and to display characteristics of the driver.

A network node does not need LAT to perform load-host functions, but LAT software is required for a system to offer services as a service node.

On remote-access ports, the DECserver 250 unit permits VAX/VMS service nodes with this software to make requests for printers on server ports. These requests are called **host-initiated requests**.

1.3 Performing the Software Installation

As software installer, you are responsible for three tasks:

1. Installing the DECserver 250 distribution software
2. Configuring the load host's node database
3. Verifying the server system installation, which includes down-line loading the server image to the DECserver and issuing a few server commands at this server.

Completion of these tasks establishes your VMS system as a load host for one or more servers. A **load host** is a system that contains the server image and whose node database has entries for specific servers, and as a result, can down-line load the server image to servers on the local Ethernet. In addition, a load host performs maintenance activities such as receiving up-line dumps from the server.

A load host can be a single VMS system, or it can be a member node of a VAXcluster. For a VMS system to act as a load host, it must be running DECnet Phase IV, and it must be located on the same Ethernet as the server. For supported version numbers of DECnet software, see the Software Product Description for the DECserver 250 product.

A load host must have 600 free blocks of disk space for the DECserver 250 distribution files. Another 768 free blocks of disk space is required for each up-line dump.

Load hosts are assigned by the network manager. Digital Equipment Corporation advises that you establish more than one system as a load host for each server. Alternate hosts free the server from dependence on one particular load host. For each server, Digital Equipment Corporation suggests a minimum of two load hosts. Digital Equipment Corporation also recommends one load host for every ten servers on a network.

When selecting alternate load hosts, you can choose any Digital Equipment Corporation system for which a DECserver 250 distribution kit is available. DECserver 250 software distribution kits are available for these systems:

- VAX/VMS
- ULTRIX-32

For information on installing the server distribution software onto another operating system and configuring that system's node database in order to establish it as an alternate load host, see the DECserver 250 software installation guide for that system.

In addition to the three tasks just described, you must coordinate the total software installation procedure with both the server hardware installer of new servers and the server manager of existing servers. For example, the software should be installed before the hardware is powered up for the first time. Chapter 4 details the coordination necessary between you, the hardware installer, and the server manager.

1.3.1 Installing the DECserver 250 Distribution Software

You install the server distribution software onto a VMS system with an automated procedure called VMSINSTAL. The DECserver 250 software distribution kit includes a procedure file that VMSINSTAL uses to do the installation. VMSINSTAL does the following:

- Copies the files from the distribution media to the load host.
- Creates the appropriate directory for these files.
- Prints the *DECserver 250 Release Notes.* VMSINSTAL gives you three choices: (1) Display the release notes, (2) Print the release notes, or (3) Display and print the release notes.

See Chapter 2 for instructions on installing the distribution software.

NOTE

If you have the Terminal Server Manager (TSM) software, an optional network management product available for VAX/VMS load hosts, read the documentation for this product before you install the DECserver 250 software. TSM affects the way you install and manage servers.

1.3.2 Required VMS Tailoring Class

The following VMS Tailoring class is required for full functionality of this product.

- VMS Required Saveset
- Network Support
- Utilities

1.3.3 Configuring the Load Host's Node Database

Once you copy the distribution software to your VMS system, you must configure the system's node database to support new servers. You configure this database with an automated procedure called DSVCONFIG. The DSVCONFIG configuration procedure file is part of the DECserver 250 software distribution kit.

Configuration of the **load host's node database** means defining an entry for each server in three places: (1) a data file called DSVCONFIG.DAT, (2) the DECnet volatile (operational) database, and (3) the DECnet permanent database. The DSVCONFIG.DAT file is the server configuration database. DSVCONFIG.DAT is automatically created by DSVCONFIG and is part of a load host's node database.

When you use DSVCONFIG to configure a new server, DSVCONFIG automatically adds an entry in the three places mentioned above. The entry identifies the server type, its DECnet node name and DECnet node address, its service circuit-ID, its Ethernet address, its dump file, and the server image.

When you complete the configuration procedure, your VMS system is established as a load host for each server that has an entry in the node database. See Chapter 3 for instructions on configuring the load host's node database to support servers.

To configure a server on a VAXcluster, install the distribution software onto one member node, and then configure the node databases of the members that you want to establish as load hosts. See Section 3.7 for details.

Besides allowing you to configure a new server in the load host's node database, DSVCONFIG allows you to list all servers currently defined in the DSVCONFIG.DAT file and to restore to the host's DECnet databases all server configurations defined in DSVCONFIG.DAT. Chapter 3 explains how to use these options. Appendix C has examples showing how to use these and two other options: (1) Replacing an existing DECserver unit with a new DECserver 250 unit (or changing the characteristics of an existing unit), and (2) removing a DECserver 250 unit from the node database. Normally you do not use these latter two options during the installation procedure. The *DECserver 250 Management Guide* explains how to use them.

1.3.4 Verifying the Installation

After configuring the node database, your final responsibility is to verify the installation. Actually, you need to perform two verifications:

1 To verify the installation of the load host, down-line load the server image to a server, and then read the DECnet event-logging messages. Verifying the installation of the load host means checking that this load host:

- Has the appropriate files in the correct directory.
- Has a correct entry in its node database for the test server.
- Can successfully down-line load the server image.

2 To verify the total server system installation, test a few server commands at an interactive terminal connected to a server port. Verifying the system installation means checking that:

- The correct version of the software is in the server.
- The server hardware operates with the new software.
- The new software is running successfully.

1.3.4.1 Verifying the Load Host Installation

To verify that your VMS system has been successfully established as a load host, use it to perform a down-line load. Down-line loading means sending the server image from an established load host to the server.

Use the NCP LOAD NODE command from your VMS load host to down-line load. Then, check the DECnet event-logging messages in order to verify that the load was successful.

1.3.4.2 Verifying the Server System Installation

Using a few server commands at an interactive terminal attached to a server port completes your verification of the server system installation.

See Chapter 4 for details on the two verification procedures. See Appendix A for a list of the DECserver 250 distribution files. See Appendix B for a brief discussion of the Remote Console Facility. Finally, see Appendix C for step-by-step examples of the entire software installation.

2 Installing the DECserver 250 Distribution Software

This chapter describes how to prepare for installation and how to install the DECserver 250 distribution software onto your VAX/VMS load host. To install the software, use VMSINSTAL.COM, an automated procedure, which is part of the VAX/VMS operating system.

2.1 Overview of VMSINSTAL

VMSINSTAL is an interactive procedure that calls and controls the DECserver 250 installation procedure. When you run VMSINSTAL, the following tasks are performed:

- Creation of a directory called SYS$SYSROOT:[DECSERVER] on the load host, if necessary
- Copying of the files from the distribution media into this directory
- Printing of a copy of the *DECserver 250 Release Notes* when you specify OPTIONS N

2.2 Preparing to Run the Installation Procedure

Before you actually run VMSINSTAL, follow these steps:

1. Determine which systems are designated as load hosts for the server. You must install the distribution software onto all of these systems. Ask your network manager or the person responsible for assigning load hosts to tell you which are the designated systems.

   Note that you do not need a separate license for each load host, but you do need a separate license for each server.

2. Check that there are 600 free blocks of disk space on each load host for copying the distribution files. Another 768 free blocks of disk space are required for each up-line dump.

3. Ensure that the network and utility classes are tailored on the load host.

2.3 VMSINSTAL Conventions

VMSINSTAL is an interactive procedure. When you start VMSINSTAL, a series of questions displays. After each question, the default response, if there is one, displays in brackets ([ ]). At the end of each question, either a colon (:) or a question mark (?) appears.

- To answer a question, type your response immediately after the colon or question mark; then press the RETURN key.
- To respond to a question with the default answer, press only the RETURN key.
- To get help after any question, type a question mark (?). After the help display, the question is repeated.

See the VAX/VMS documentation for a complete description of VMSINSTAL.

2.4 Running VMSINSTAL

Running VMSINSTAL.COM requires the appropriate privileges. To determine what they are, see the system manager.

Run VMSINSTAL.COM from the system manager's account. The installation procedure takes approximately 10 to 15 minutes. Follow these steps:

1 Place the distribution medium on the appropriate device drive.

2 Log in to the system manager account.

3 Start VMSINSTAL with these commands:

```
$ SET DEFAULT SYS$UPDATE RET
$ @VMSINSTAL DS25 device-identifier OPTIONS N RET
```

Here, DS25 is the VAX/VMS facility code for the DECserver 250 product, and *device-identifier* is the device on which the distribution medium is mounted. During the procedure, OPTIONS N tells VMSINSTAL to ask if you want to print the *DECserver 250 Release Notes.*

NOTE

Digital Equipment Corporation recommends that you specify OPTIONS N on the command line. If you do not want to print the release notes or if you are interested in VMSINSTAL's other options, see the *VAX/VMS Guide to Software Installation*, which is part of the VAX/VMS documentation set.

If you are installing onto alternate load hosts with copied Savesets, the VMSINSTAL command line format differs slightly. See the VAX/VMS documentation on VMSINSTAL.

NOTE

To abort the installation procedure at any time, press CTRL/Y. When you press CTRL/Y, the installation procedure deletes all files it has created up to that point and then returns you to DCL level. If you want to retry the installation procedure after pressing CTRL/Y, you must invoke VMSINSTAL again.

VMSINSTAL displays the procedure title and the date and time. It continues with the following (the warning message appears only if DECnet is running):

```
%VMSINSTAL-W-DECNET, Your DECnet network is up and running.
* Do you want to continue anyway [NO]?
```

4 Type YES and press the RETURN key to proceed with the installation.

5 VMSINSTAL asks:

```
* Are you satisfied with the backup of your system disk [YES]?
```

6 If you answer NO, the installation procedure terminates. Take appropriate action and start the procedure again.

If backup is satisfactory, press the RETURN key to answer YES.

7 If you are installing from the distribution media rather than from copied Savesets, VMSINSTAL prompts you to mount the first volume:

```
Please mount the first volume of the set on device-identifier.
* Are you ready?
```

Type YES and press the RETURN key. A confirmation message says that the medium is mounted.

8 The procedure continues:

```
The following products will be processed:

  DS25 Vn.n

        Beginning installation of DS25 Vn.n at hh:mm

%VMSINSTAL-I-RESTORE, Restoring product saveset A...
```

NOTE

DECserver 250 software version numbers are not specified in this manual. For example, the release notes file is shown as DS25*nnn*.RELEASE_NOTES. Here, *nnn* represents the version number; if you are installing Version 1.0, the release notes file is DS25010.RELEASE_ NOTES.

9 Some types of distribution media require several volumes. (More than one distribution medium is delivered with your distribution kit.) For these types of distribution media, the procedure gives you a continuation message and tells you to mount the next volume (each volume is labeled with a volume number):

```
%BACKUP-I-READYREAD, mount volume 2 on device-identifier: for reading
Enter "YES" when ready:
```

Mount the next volume, type YES, and press the RETURN key.

10 The procedure lists your options for printing and displaying the release notes:

```
Release Notes Options:

        1.  Display release notes
        2.  Print release notes
        3.  Both 1 and 2
        4.  Copy release notes to SYS$HELP
        5.  Do not display, print or copy release notes

* Select option [2]:
```

Select one of these options. Digital Equipment Corporation recommends that you select Option 2.

- If you select Option 1, you see:

  VMI$ROOT:[SYSUPD.DS25*nnn*]DS25*nnn*.RELEASE_NOTES;1

  The release notes immediately start scrolling at your terminal.

  NOTE
  The release notes might contain up to 30 pages.

- If you select Option 2, VMSINSTAL asks to which queue you want to send the file for printing:

  ```
  * Queue name [SYS$PRINT]:
  ```

  Press the RETURN key to print the release notes on the default printer, or specify another print queue. A message indicates that the system queued the file.

- If you select Option 3, VMSINSTAL first asks to which queue you want to send the file for printing:

  ```
  * Queue name [SYS$PRINT]:
  ```

  Press the RETURN key to print the release notes on the default printer, or specify another print queue. A message indicates that the system queued the file for printing. Next, VMSINSTAL displays the release notes:

  VMI$ROOT:[SYSUPD.DS25*nnn*]DS25*nnn*.RELEASE_NOTES

  The release notes immediately start scrolling at your terminal.

11 After the system's queue message and the release notes are displayed (if you selected one of the display options), the procedure continues by asking:

```
* Do you want to continue the installation [N]?
```

Press the RETURN key to stop the procedure and review the release notes. Check for any changes that can affect this installation. (VMSINSTAL places the release notes file, DS25*nnn*.RELEASE_NOTES, in the SYS$HELP directory.)

12 Run the procedure again when you are ready to continue. Enter this form of the command:

```
$ @VMSINSTAL DS25 device-identifier RET
```

13 VMSINSTAL displays the procedure title and the date and time. It continues with the following (the warning message appears only if DECnet is running):

```
%VMSINSTAL-W-DECNET, Your DECnet network is up and running.
* Do you want to continue anyway [NO]?
```

Type YES and press the RETURN key to proceed with the installation.

14 VMSINSTAL asks:

```
* Are you satisfied with the backup of your system disk [YES]?
```

Press the RETURN key to answer YES.

15 If you are installing from the distribution media rather than from copied Savesets, VMSINSTAL prompts you to mount the first volume:

```
Please mount the first volume of the set on device-identifier.
* Are you ready?
```

Type YES and press the RETURN key.

16 A confirmation message says that the medium is mounted. The procedure continues:

```
The following products will be processed:

  DS25 Vn.n

        Beginning installation of DS25 Vn.n  at hh:mm

%VMSINSTAL-I-RESTORE, Restoring product saveset A...
%VMSINSTAL-I-RELMOVED, The product's release notes
have been successfully moved to SYS$HELP.
* Do you want to run the IVP after the installation [YES]?
```

17 If your distribution media require more than one volume, the procedure gives you a continuation message and tells you to mount the next volume. Each volume is labeled with a volume number.

```
%BACKUP-I-READYREAD, mount volume 2 on device-identifier: for reading
Enter "YES" when ready:
```

Mount the next volume, type YES, and press the RETURN key.

18 If you are on a VAXcluster node, the following message displays:

```
If you intend to execute this layered product on other nodes in your
VAXcluster, and you have the appropriate software license, you must
prepare the system-specific roots on the other nodes by issuing the
following command on each node (using a suitably privileged account):

$ CREATE/DIRECTORY SYS$SPECIFIC:[DECSERVER]/PROTECTION=(S:RWED,O:RWED)
```

19 You have finished the first part of the installation. The procedure continues:

- It tells you that the installation is complete, meaning that all the distribution files have been copied to their appropriate directories. (See Appendix A for descriptions of the DECserver 250 VMS distribution files.)
- It instructs you how to continue.
- It mentions the additional software you must install at this time.

```
Your installation is now complete. After exiting from VMSINSTAL:

1. Edit your system start-up file so that it defines the logical
   MOM$LOAD as a search string with a value equal to the current search
   string plus the added element SYS$SYSROOT:[DECSERVER]. For example:

   DEFINE/SYSTEM/EXEC/NAME_ATTRIBUTE=NO_ALIAS/NOLOG-
   MOM$LOAD 'current-search-string',SYS$SYSROOT:[DECSERVER]

   If the current search string associated with MOM$LOAD in your
   start-up file is SYS$SYSROOT:[DECSERVER] or if you have
   already made this change for a previous installation, there
   is no need to edit this file.

   This command ensures that the location of the server image
   is defined each time the system is rebooted, necessary for
   successful down-line loading.


2. Configure the server into your host's database.
   Execute a command procedure called DSVCONFIG.COM. This
   command procedure is in the SYS$SYSROOT:[DECSERVER] directory.
   If you have already executed this procedure from previous
   installations, you need to configure only any additional units.
   All previously defined units will still be configured.

3. The Installation Verification Procedure (IVP) for the DECserver 250
   can be found in SYS$TEST and may be run at any time by executing the
   command procedure DS25$IVP.COM.
```

20 VMSINSTAL runs the Installation Verification Procedure:

```
%VMSINSTAL-I-RESTORE, Restoring product saveset B...
%VMSINSTAL-I-MOVEFILES, Files will now be moved to
their target directories
...


Beginning installation verification procedure for
DECserver 250 Vn.n.

Successfully located SYS$SYSROOT:[DECSERVER] directory

Successfully located SYS$SYSROOT:[DECSERVER]DS25nnn.RELEASE_NOTES

Successfully located SYS$SYSROOT:[DECSERVER]DP0601ENG.SYS

Successfully located SYS$SYSROOT:[DECSERVER]DSVCONFIG.COM

Successfully located SYS$SYSROOT:[DECSERVER]DSVCONFIG.DAT

Successfully located SYS$SYSROOT:[DECSERVER]DS25_nnn_DEFAULTS.COM


Installation verification procedure for DECserver 250
Vn.n successful.
 Installation of DS25 Vn.n completed at nn:nn

VMSINSTAL procedure done at nn:nn
$
```

NOTE

If you are installing files onto a VAXcluster node, the messages indicate that the files are copied to the SYS$COMMON:[DECSERVER] directory.

MOM$LOAD is a logical name that your load host uses to find the image file of any product that must be down-line loaded. For each product, MOM$LOAD has an associated equivalent string that specifies the location of the product's image file. Thus, the following command equates the logical name MOM$LOAD to the location of your DECserver 250 image file:

```
DEFINE/SYSTEM/EXEC/NAME ATTRIBUTE=NOALIAS/NOLOG MOM$LOAD -
SYS$SYSTEM:[DECSERVER]
```

If your system is a load host for several products, then the location of each image file must be defined by a list of equivalent strings. For example, the following command defines the location of a LAN Bridge image file as well as the DECserver 250 image file:

```
DEFINE/SYSTEM/EXEC/NAME_ATTRIBUTE=NOALIAS/NOLOG MOM$LOAD -
SYS$SYSTEM:[LANBRIDGE],SYS$SYSTEM:[DECSERVER]
```

Two or more equivalence strings make up a search list. When your VAX/VMS system is requested to down-line load a product, it looks through the search list until it finds the location of the product's image file.

Your host cannot down-line load the DECserver 250 image file unless the search list defined for MOM$LOAD has the correct location of the image file. To see what the current search string is for MOM$LOAD, use the DCL SHOW LOGICAL command:

```
$ SHOW LOGICAL MOM$LOAD RET
```

If SYS$SYSROOT:[DECSERVER] is defined for MOM$LOAD, you do not have to define MOM$LOAD. Define MOM$LOAD only if:

- No equivalent string exists for MOM$LOAD (the SHOW LOGICAL command results with the message, "No translation for logical name MOM$LOAD")

  or

- The equivalent strings defined for MOM$LOAD do not include SYS$SYSROOT:[DECSERVER].

If MOM$LOAD is already defined for other products but not for the DECserver 250 product, you must define MOM$LOAD by specifying SYS$SYSROOT:[DECSERVER] along with the current search string(s), as shown in the VMSINSTAL example. If you specify only SYS$SYSROOT:[DECSERVER] for MOM$LOAD excluding the current search string(s), then SYS$SYSROOT:[DECSERVER] will replace the current search string(s). Your VAX/VMS system will not be able to load the image files located by the current search string(s).

21 Depending on your system, VMSINSTAL may now let you make an entry in the Software History log. The procedure concludes:

```
        VMSINSTAL procedure done at hh:mm

$
```

See Section 2.7 for the next step.

2.5 Special Installation Considerations for DSVCONFIG.COM

The configuration command procedure, DSVCONFIG.COM, which is part of this distribution kit, accommodates the DECserver 100, DECserver 200, DECserver 250, and DECserver 500 products. However, some previous releases of DSVCONFIG.COM cannot accommodate the DECserver 250 and DECserver 500 products. Therefore, for all configurations use the command file on your kit only.

When installing new versions of DECserver products, always check the product release notes for information on the latest DSVCONFIG.COM.

2.6 Installing onto Alternate Load Hosts

Digital Equipment Corporation recommends that you establish alternate load hosts for each server. Alternates free the server from dependence on one particular load host because an alternate load host can perform a down-line load if the original load host is unavailable. In addition, alternate load hosts can receive up-line dumps from servers.

Regarding the assignment of load hosts, Digital Equipment Corporation suggests both the following:

- For each server, at least one other load host as a backup to the original.
- At least one load host for every ten servers.

As with the original load host, an alternate VAX/VMS load host must:

- Be running DECnet Phase IV.
- Have an Ethernet controller on the same Ethernet as the server.
- Have the distribution software installed.

- Have DECserver 250 entries in its server configuration database (DSVCONFIG.DAT file), the DECnet operational database, and the DECnet permanent database.
- Have the latest load file (see Chapter 3).
- Have its Ethernet circuit enabled for service.

2.6.1 Installing onto Single Systems

To install the server distribution software onto an alternate VAX/VMS load host that is not a member of a VAXcluster, use one of these methods:

- If the alternate load host has the same load device as the original host, place your distribution media on the appropriate device of the new load host and repeat the installation procedure detailed in Section 2.4.
- If the alternate load host does not have the same load device as the original host, load and extract the savesets from the kit, using the following procedure:

  1 Type the following command on the original load host:

  ```
  $SET DEFAULT SYS$UPDATE: RET
  $@VMSINSTAL DS25 device-identifier OPTIONS G SYS$UPDATE: RET
  ```

  Here, DS25 is the VMS four-letter facility code for the DECserver 250 product. OPTIONS G extracts the savesets from the kit.

  2 Copy the savesets to the alternate load host's SYS$UPDATE directory. The savesets are DS25nnn.A and DS25nnn.B.

  3 Run VMSINSTAL on the alternate load host:

  ```
  $@VMSINSTAL DS25 SYS$UPDATE: RET
  ```

2.6.2 Installing onto VAXclusters

To install the server distribution software onto an alternate load host that is a member of a VAXcluster, follow these steps:

1. Run DSVCONFIG on all cluster members that are to act as load hosts. (Do not reinstall the software on homogeneous clusters.)

   The software is installed onto the common cluster disk. Since the distribution files are in SYS$COMMON:[DECSERVER], all cluster members have access to them.

2. Follow the steps in Section 3.7 to keep accurate each member's three databases for servers.

2.6.3 Installing onto Other Operating Systems

To install the DECserver 250 distribution software onto an operating system other than VAX/VMS, follow the instructions in the *DECserver 250 Software Installation Guide* for that system. You can find the guide for one of the other supported operating systems in the software distribution kit for that operating system. You can also order separately any *DECserver 250 Software Installation Guide* for another operating system.

2.7 After Exiting VMSINSTAL

After you exit VMSINSTAL, follow these steps:

1. Check the *DECserver 250 Release Notes* to see if you have to install any additional software from the distribution media. If so, install those distribution files.
2. Give the *DECserver 250 Release Notes* to the server manager.
3. Run the configuration procedure, DSVCONFIG.COM, to configure the load host's node database. See Chapter 3 for information about this procedure.

3 Configuring the Load Host's Node Database

This chapter explains how to configure a VAX/VMS load host's node database for new servers. Configuring this database is part of the software installation. After this procedure, your VAX/VMS system is established as a valid load host for the new servers.

To configure the load host's node database for a new server, use the Add option of DSVCONFIG.COM, an automated, menu-driven procedure. DSVCONFIG.COM prompts you for information about the new server and then configures the load host's node database by adding an entry for the new server to the DSVCONFIG.DAT file (the server configuration database) and the DECnet databases. You also can configure the load host's node database by restoring to the DECnet databases the server entries that exist in the DSVCONFIG.DAT file.

If you ran the installation procedure described in Chapter 2, DSVCONFIG.COM is now in the SYS$SYSROOT:[DECSERVER] directory for single systems and in SYS$COMMON:[DECSERVER] for VAXcluster members. The load host creates and maintains all server-related files in this directory.

NOTE

DSVCONFIG.COM, which is part of this distribution kit, accommodates the DECserver 100, DECserver 200, DECserver 250 and DECserver 500 products. However, some previous releases of DSVCONFIG.COM do not accommodate the DECserver 250 and DECserver 500 products. Therefore, use the command file on this kit for all configurations.

3.1 Overview of DSVCONFIG

DSVCONFIG has five configuration options, all of which affect the node database on the load host. When you start the DSVCONFIG procedure, it displays the following menu of options:

```
DECserver Configuration Procedure

        Menu of Options
   1 - List known DECservers
   2 - Add a DECserver
   3 - Swap an existing DECserver
   4 - Delete an existing DECserver
   5 - Restore existing DECservers
CTRL/Z - Exit from this procedure
```

To configure your load host's node database for new servers, use the List and Add options. You may also need to use the Restore option (especially for configuring VAXcluster nodes). This chapter discusses these three options only. The Swap and Delete options are used by the server manager. The Swap option is recommended when the server hardware unit malfunctions and must be replaced. The Delete option is useful when reconfiguring the network or changing load hosts for a server. Examples showing the uses of these options are included in Appendix C. For more information on these options and DSVCONFIG, see the *DECserver 250 Management Guide*.

This section discusses the databases that the DSVCONFIG options affect. Subsequent sections explain how to:

- Specify DECnet characteristics during DSVCONFIG (Section 3.2).
- Prepare for running DSVCONFIG (Section 3.3).
- Respond to DSVCONFIG and comply with its requirements (Section 3.4).
- Start DSVCONFIG and use the List, Add, and Restore options (Section 3.5).
- Start DSVCONFIG with the RESTORE parameter to restore your local DECnet database (Section 3.6).
- Configure VAXcluster nodes using DSVCONFIG (Section 3.7).

- Exit from DSVCONFIG (Section 3.8).

See the *DECserver 250 Management Guide* for a complete description of DSVCONFIG.

3.1.1 Databases Affected by DSVCONFIG

The DSVCONFIG procedure operates on three distinct databases contained in the load host's node database:

1. The server configuration database for servers. This database is stored in the file DSVCONFIG.DAT. It has the information you see when you select Option 1, List, from the DSVCONFIG Menu.
2. The operational host DECnet database.
3. The permanent host DECnet database.

When you run DSVCONFIG, server information is transferred from the DSVCONFIG database to the DECnet database. These two databases must remain synchronized.

The DSVCONFIG procedure automatically keeps these databases synchronized on the load host. Though DSVCONFIG includes several NCP commands, do not execute these commands yourself to configure the load host's node database. NCP affects only the DECnet databases.

On a VAXcluster load host, the DSVCONFIG procedure automatically synchronizes the databases on the load host but not on the other members of the VAXcluster. Section 3.7 explains how to configure VAXcluster nodes so that the databases are synchronized on all members.

3.1.2 DSVCONFIG Options for the Software Installer

As a software installer, use the List, Add, and Restore DSVCONFIG options for new servers.

1. List known DECservers—Lists servers that are currently defined in DSVCONFIG.DAT.
2. Add a DECserver—Adds an entry for a new server in DSVCONFIG.DAT and in the DECnet databases.

   Adding an entry supplies information that identifies the server on the Ethernet, thus establishing this system as a load host for the new server.

3 Restore existing DECservers – Restores servers that exist in the DSVCONFIG.DAT file to the load host's DECnet operational database and DECnet permanent database.

This option copies server entries from DSVCONFIG.DAT to the DECnet databases. For example, if the load host system is brought down, server entries may not be automatically restored to the DECnet databases when the system comes up again, especially if a central node database is used with NCP. Because server entries remain intact in the DSVCONFIG.DAT file, you can use the Restore option to copy these server entries to the DECnet databases.

3.2 Specifying DECnet Characteristics During DSVCONFIG

Several DECnet characteristics apply to servers. DECnet uses these characteristics for down-line loading and up-line dumping. For each new server, you must specify some of the following characteristics; DSVCONFIG supplies the others automatically.

DECnet Characteristics	You Specify	DSVCONFIG Supplies
DECnet node address	X	
DECnet node name	X	
Server type	X	
Service circuit ID	X	
Ethernet address	X	
Load file		X
Dump file name		X

The DECserver 250 information that you must specify is recorded on each unit's *DECserver 250 Identification Card*. Ask the hardware installer or the network manager for this card.

3.2.1 DECnet Node Name

Each DECserver 250 unit must have a unique DECnet node name. This name must have from 1 to 6 alphanumeric characters with at least one character being an alphabetic character. For example, DSV25 and LION77 are valid DECnet node names.

The network manager assigns DECnet node names. During the hardware installation, the hardware installer records the DECnet node name on the *DECserver 250 Identification Card* for each server.

DSVCONFIG does not set up the server name on the server itself. The server name, a server characteristic stored in the server's databases, must be defined on the server by the server manager. To avoid confusion, the server name should match the DECnet node name.

3.2.2 DECnet Node Address

Each DECserver 250 unit has a unique DECnet node address. This number must be a decimal number from 1 to 1023.

If your DECnet network is divided into areas, each DECnet node address takes the form *aa.nnnn*. Here, *aa* is a decimal area number from 2 to 63, *nnnn* is the node address, and the period distinguishes area from address. For example, 17.1003 is a valid node address.

The network manager assigns DECnet node addresses. During the hardware installation, the hardware installer records the DECnet node address on the *DECserver 250 Identification Card* for each server.

3.2.3 Ethernet Address

Each DECserver 250 unit is delivered with a unique Ethernet hardware address. This address is six pairs of hexadecimal digits with a hyphen (-) separating each pair. For example, 08-00-01-00-AB-CD is an address with a valid format.

The Ethernet address is on the control/indicator panel of the DECserver 250 unit. During the hardware installation, the hardware installer records the Ethernet address on each unit's *DECserver 250 Identification Card*.

3.2.4 Server Type

The server type that you specify is "DS250", which defines your unit as a DECserver 250 server.

3.2.5 Load File (Server Image File)

The DECserver 250 load file is the server's software image that is down-line loaded by the host to the server. You do not have to supply this information.

The name of the DECserver 250 load file is DP0601ENG.SYS.

3.2.6 Dump File Name

Each server has a unique dump file name, DP2*node-name*.DMP. Here, *node-name* is the DECnet node name of the server. For example, a DECserver 250 unit with the DECnet node name TIGER has the dump file name DP2TIGER.DMP.

You do not have to supply the dump file name. When you use the Add option to define a new DECserver 250 unit, DSVCONFIG assigns a name for the dump file. See the *DECserver 250 Problem Determination Guide* for information on up-line dumping, the creation of the server's up-line dump file, and using this file for problem analysis.

3.2.7 Service Circuit

The service circuit is the Ethernet circuit that the load host uses to reach the server when loading and dumping occur. The load host may have more than one active Ethernet circuit, so you have to specify the service circuit ID to identify which circuit is to be used for loads and dumps. The service circuit ID is stored in the load host's DECnet databases.

DSVCONFIG prepares your node as a load host by enabling SERVICE on the service circuit. SERVICE must be enabled before a down-line load can occur.

Service Circuit ID	Ethernet Controller
UNA-*n*	DEUNA, DELUA
QNA-*n*	DEQNA, DELQA, DESQA
BNT-*n*	DEBNA, DEBNT
SVA-*n*	DESVA (DIGITAL Ethernet Small VAX Adapter)

Here, *n* is an integer (typically 0 or 1).

When you run DSVCONFIG to add more than one unit, the procedure asks you to specify the service circuit each time. The first time you are asked, the default is the service circuit for the processor type of your VAX/VMS load host. If you respond by specifying a different service circuit, that response becomes the default until either you specify another service circuit or you exit the procedure.

The possible default values for each load host's CPU type are:

CPU Type	Service Circuit ID
VAX–11/780, 785	UNA-0
VAX–11/730,750	UNA-0
VAX 6210, 6220, 6230, 6240	BNT-0
VAX 8250, 8350, 8530, 8810 8820, 8830, 8840, 8974, 8978	BNT-0
VAX 8600, 8650	UNA-0
VAX 8200, 8300, 8500, 8550, 8700, 8800	UNA-0 or BNT-0
MicroVAX II	QNA-0
VAXstation II	QNA-0
MicroVAX 2000, 3300/3400	SVA-0
MicroVAX 3500/3600/3800/3900	QNA-0
VAXstation 2000	SVA-0
VAXstation 3200/3500	QNA-0
VAXserver 3500/3600/3602/3800	QNA-0

If your CPU supports more than one Ethernet controller, you can choose a service circuit ID number other than zero.

3.3 Preparing to Run the Configuration Procedure

Before beginning the configuration procedure:

1. Check that DECnet Phase IV is installed and running. For information about DECnet Phase IV, see the *VAX/VMS DECnet–VAX System Manager's Guide*.
2. Check that all the distribution software was installed in these directories:
   - SYS$SYSROOT:[DECSERVER] for single systems
   - SYS$COMMON:[DECSERVER] for VAXclusters

   See Appendix A for a list of the distribution files.

3 Check that each new server's DECnet node name and node address are unique.

Ask the hardware installer for the *DECserver 250 Identification Card* for each new DECserver 250 unit. The network manager and the hardware installer recorded the server's DECnet node name and node address as well as the Ethernet address on this card. You need to know the server's DECnet node name, DECnet node address, and Ethernet address to answer prompts during DSVCONFIG.

You can check the uniqueness of the server's DECnet node address and node name by specifying the address or name with the NCP SHOW NODE command:

```
$ MCR NCP RET
NCP>SHOW NODE node-name CHARACTERISTICS RET

or

NCP>SHOW NODE node-number CHARACTERISTICS RET
```

If NCP shows a node already defined, see the network manager to resolve the conflict in names.

3.4 DSVCONFIG Conventions and Requirements

DSVCONFIG is an interactive procedure. When you start DSVCONFIG, a menu of options displays. Within the Add option, you get a series of questions. After each question, the default response, if there is one, displays in brackets ([ ]). At the end of each question, either a colon (:) or a question mark (?) appears. The following list tells you how to use DSVCONFIG:

- To select an option, type a menu number and press the RETURN key.
- To answer a question, type your response immediately after the colon or question mark, and press the RETURN key.
- To respond to a question with the default answer, press only the RETURN key.
- To get help after any question, type a question mark (?). After the help display, the question is repeated.
- To exit an option without making any changes, type CTRL/Z. You are returned to the DSVCONFIG Menu.
- To exit DSVCONFIG at the menu level, type CTRL/Z. You are returned to the DCL prompt.

DSVCONFIG has some additional conventions and requirements:

- When you finish an option, DSVCONFIG automatically returns you to the DSVCONFIG Menu.
- At the end of the Add option, you might get NCP messages (information, confirmations, and errors). In the case of error messages, the operation might not have been successful. For the meanings of these messages, see the *VAX/VMS System Messages and Recovery Procedures Reference Manual*.
- For you to run DSVCONFIG on a particular VAX/VMS load host, the distribution software must already be installed onto that system.

3.5 Running DSVCONFIG

To run DSVCONFIG.COM, you need OPER and SYSPRV privileges. To start DSVCONFIG:

1. Log in to the system account or any account with OPER and SYSPRV privileges.
2. Enter the following commands:

```
$ SET DEFAULT MOM$LOAD RET
$ @DSVCONFIG RET
```

NOTE

The latter command assumes you have defined MOM$LOAD to locate the DECserver 250 software image in SYS$SYSROOT:[DECSERVER]. See Section 2.4.

DSVCONFIG starts with these actions:

- It determines whether the DECnet key is installed. If DECnet is missing, DSVCONFIG prints a message and exits. You must have DECnet to run this procedure.
- It checks the existence and format of a data file called DSVCONFIG.DAT. It finds one of three possible situations and continues accordingly:

  a. The DSVCONFIG.DAT file does not exist in SYS$SYSROOT:[DECSERVER]. The procedure creates DSVCONFIG.DAT and displays a message telling you that the file was not found and a new one was created.

b. SYS$SYSROOT:[DECSERVER] already has this file, formatted correctly. This is the case if DSVCONFIG was previously used to add DECserver 250 entries. The procedure continues with its next task.

c. SYS$SYSROOT:[DECSERVER] (or for VAXclusters, SYS$SPECIFIC:[DECSERVER]) already has this file, but not in the correct format. The procedure reformats the file. Regarding VAXclusters, SYS$SPECIFIC:[DECSERVER] on each VAXcluster node may have an older version of the DSVCONFIG.DAT file. The DSVCONFIG procedure copies the server entries from that data file into the DSVCONFIG.DAT file on SYS$COMMON:[DECSERVER], a directory shared by the VAXcluster nodes. The procedure renames the DSVCONFIG.DAT file in SYS$SPECIFIC so that the DSVCONFIG.DAT file in SYS$COMMON is used thereafter.

NOTE

On VAXclusters, DSVCONFIG creates and writes files in the common area, SYS$COMMON:[DECSERVER]. See Section 3.7 for special instructions on running DSVCONFIG for the first time on VAXclusters.

- It informs you that each DECserver unit must have a unique DECnet node name and DECnet node address.
- It asks you either to continue or to exit:

```
Press RET to start, or CTRL/Z to exit...
```

Press the RETURN key if you have the information you need for each new server.

3 DSVCONFIG displays:

```
                DECserver Configuration Procedure

                      Menu of Options
                  1 - List known DECservers
                  2 - Add a DECserver
                  3 - Swap an existing DECserver
                  4 - Delete an existing DECserver
                  5 - Restore existing DECservers
                CTRL/Z - Exit from this procedure

     Your selection?
```

Type the number of the option you want. Then press the RETURN key.

3.5.1 List Known DECservers (Option 1)

Select Option 1 to list the DECserver units in the DSVCONFIG.DAT data file. Type 1 and press the RETURN key. The contents of the DSVCONFIG.DAT file displays in seven columns. Option 1 displays a listing such as this:

```
DECnet  DECnet Server Service
Address Name   Type   Circuit Ethernet Address  Load File     Dump File
------- ------ ------ ------- ----------------- ------------- -------------

28.900  BUNNY  DS250  BNT-0   08-00-2B-02-F0-99 DPO601ENG.SYS DP2BUNNY.DMP
28.1001 BACH   DS200  UNA-0   08-00-2B-02-24-CC PR0801ENG.SYS DS2BACH.DMP
28.1002 BEETHO DS200  UNA-0   08-00-2B-03-AA-2B PR0801ENG.SYS DS2BEETHO.DMP
28.1003 MOZART DS100  UNA-0   08-00-2B-02-24-DD PS0801ENG.SYS PSDMP24DD.SYS
28.1005 HAYDN  DS200  UNA-1   08-00-2B-03-AA-F1 PR0801ENG.SYS DS2HAYDN.DMP
28.1019 OCELOT DS500  UNA-0   08-00-2B-03-EE-FF DS5OCELOT.SYS DS5OCELOT.DMP
28.1022 JAGUAR DS500  UNA-0   08-00-2B-03-E1-F1 DS5JAGUAR.SYS DS5JAGUAR.DMP
28.1023 BEATLE DS100  UNA-0   08-00-2B-02-24-2D PS0801ENG.SYS PSDMP242D.SYS

Total of 8 DECservers defined.

(Press RETURN for menu)
```

3.5.2 Add a DECserver (Option 2)

Select Option 2 to add an entry for a new server in the server configuration database (DSVCONFIG.DAT), the DECnet operational database, and the DECnet permanent database. To create an entry, you must supply:

- The DECserver type
- A unique DECnet node name for the DECserver unit
- A unique DECnet node address for the DECserver unit
- The Ethernet address of the DECserver unit
- The service circuit

To add a server, follow these steps:

1 Type 2 and press the RETURN key.

2 DSVCONFIG asks:

```
DECserver type?
```

Type DS250 and press the RETURN key.

3 DSVCONFIG asks:

```
DECnet node name for unit?
```

Specify the DECnet node name for the new server.

4 DSVCONFIG asks:

```
DECnet node address for unit?
```

Specify the DECnet node address for the new server.

5 DSVCONFIG asks:

```
Ethernet address of unit?
```

Specify the Ethernet address of the new server.

6 DSVCONFIG asks:

```
DECnet Service Circuit-ID [default-id]?
```

Press the RETURN key if the default service circuit is the same as the circuit that connects the load host to the same Ethernet as the server. If not, specify the service-circuit ID of the desired Ethernet controller:

- UNA-*n* for DEUNA or DELUA
- QNA-*n* for DEQNA, DELQA, DESQA
- BNT-*n* for DEBNA, DEBNT
- SVA-*n* for DESVA

Here, *n* is an integer (typically 0 or 1). See Section 3.2.7 for a discussion of service circuits.

DSVCONFIG adds the entry for the new server to the databases and sets SERVICE ENABLED on the specified service circuit, both of which are necessary for down-line loading.

CAUTION

If you get an error from DECnet while you are adding a server, the entry is added to the DSVCONFIG.DAT file even though it is not entered in the DECnet databases. To correct this synchronization problem, follow these steps:

1 Use Option 4 to delete the entry. (See the example in Appendix C, or refer to the *DECserver 250 Management Guide.*)

2 Fix the condition causing the DECnet error.

3 Return to Option 2 to add the server again with the correct information.

If you specify a node address that is already defined in DSVCONFIG.DAT, you get a DSVCONFIG error, nothing is added, and the Add option is terminated.

3.5.3 Restore Existing DECservers (Option 5)

Select Option 5 to restore your system's DECnet databases to include the servers in DSVCONFIG.DAT. The Restore option affects both the operational and permanent DECnet databases. It performs NCP SET and NCP DEFINE commands.

If your DECnet network contains a large number of nodes, you might store your DECnet database on a central remote node and copy this database upon each system startup. However, if many servers exist on the network, Digital Equipment Corporation advises against defining these servers in that central database.

If servers are not defined in the central database, you must restore them whenever you copy your local DECnet database from the central DECnet database. Each time you copy the central DECnet database, use Option 5 to restore existing server configurations.

Type 5 and press the RETURN key. The following messages confirm the restoration:

```
Restoring existing DECservers to host DECnet database...
Host DECnet database successfully restored.
```

3.6 Restoring with the RESTORE Parameter and from Your Start-up Procedure

There is another way, which can be automated, to restore your local DECnet database. Run DSVCONFIG with the RESTORE parameter:

```
$ @DSVCONFIG RESTORE RET
```

Using RESTORE bypasses the menu and lets you include this restoration in your system start-up procedures. If you want to restore servers to the DECnet database at system startup, edit your system start-up file. Then edit your start-up procedure so that it follows this sequence:

1. Starts DECnet.
2. Defines all DECnet node names.
3. Restores servers. Use the following command in the start-up file:

```
$ @SYS$SYSROOT:[DECSERVER]DSVCONFIG RESTORE
```

For VAXcluster nodes, a fourth step is sometimes required. For each node that has a different service circuit ID from the rest of the nodes on the cluster, add another line to your start-up procedure:

@SYS$COMMON:[DECSERVER]DSVCONFIG SET_CIRCUIT *service-circuit-ID*

See Section 3.2.7 for a list of valid service circuit IDs.

The SET_CIRCUIT parameter is similar to the RESTORE parameter, but SET_CIRCUIT affects only the DECnet operational (not the permanent) database. This parameter ensures the correct definitions for service circuit IDs for each node after a cluster reboot. DSVCONFIG RESTORE and DSVCONFIG SET_CIRCUIT also turn on all the specified service circuits.

3.7 Configuring on VAXcluster Nodes

For VAXcluster nodes as load hosts, you must keep up to date each node's databases. The procedure you should follow depends on whether you are running for the first time the version of DSVCONFIG in your DECserver 250 software distribution kit.

3.7.1 Running DSVCONFIG for the First Time

Older versions of DSVCONFIG place DSVCONFIG.DAT in the SYS$SPECIFIC directory. When you run the version of DSVCONFIG in your DECserver 250 software distribution kit for the first time, follow this procedure to ensure that DSVCONFIG updates the DSVCONFIG.DAT file correctly and places it in the SYS$COMMON directory:

1 Run DSVCONFIG at one node to add servers. DSVCONFIG looks for the original DSVCONFIG.DAT in the SYS$SPECIFIC directory.

Finding an existing DSVCONFIG.DAT file, DSVCONFIG copies the server entries from that data file into the DSVCONFIG.DAT file on SYS$COMMON:[DECSERVER], ignoring any servers with names already existing in the SYS$COMMON file. The procedure looks at each entry in SYS$SPECIFIC and determines if that entry is already in SYS$COMMON. If the entry is in SYS$COMMON, it is not merged. If the entry is not in SYS$COMMON, it is merged.

Then, DSVCONFIG renames the old DSVCONFIG.DAT file on the SYS$SPECIFIC directory to DSVCONFIG_SPECIFIC.DAT. As a result, you still have the original entries in case you need to repeat the merge.

2 At every other node, run DSVCONFIG and select the List option. DSVCONFIG merges all the existing server entries to the DSVCONFIG.DAT file in SYS$COMMON.

3 Verify that the merge was successful. The list should display the correct service circuit IDs at each node. Since the individual nodes have the correct service circuit ID for each server entry, the correct IDs are merged into the new file. Informational messages display the status of the merge as it progresses.

After you verify that the merge is successful, delete the DSVCONFIG_SPECIFIC.DAT file.

If the service circuit IDs are not correct for a particular node, you can correct them in one of two ways. You can run DSVCONFIG at the node with the errors. Use the Swap option to change the service circuit IDs, or run DSVCONFIG SET_CIRCUIT at that node (for VAXclusters, the latter method is better).

The following example shows the messages DSVCONFIG displays as it merges old server entries:

```
$ @DSVCONFIG RET

Merging SYS$SPECIFIC:[DECSERVER]DSVCONFIG into SYS$Common:[DECSERVER])DSVCONFIG

8 servers were defined in SYS$SPECIFIC:[DECSERVER]DSVCONFIG.DAT
3 servers were already in SYS$COMMON:[DECSERVER]DSVCONFIG.DAT
5 servers merged into SYS$COMMON:[DECSERVER]DSVCONFIG.DAT

You must assign a unique DECnet node  name  and  DECnet  node
address for each new DECserver unit.

Press  RET  to start, or  CTRL/Z  to exit...
```

3.7.2 Running This Version of DSVCONFIG Again

To establish the system as a load host immediately and make additional configuration changes for servers, run DSVCONFIG at each node and select the appropriate options. Running DSVCONFIG at each node ensures correct service circuit IDs. Use the Restore option at each node. This option restores the server's DSVCONFIG.DAT definitions into each node's NCP database.

You do not have to perform the procedure at each node if you can wait for the next reboot of the system before it can act as a load host. At reboot, the start-up procedures correct all service circuit IDs for each node.

3.8 Exiting DSVCONFIG

When you exit DSVCONFIG:

1. Give the server manager the *DECserver 250 Identification Card* for each server that you defined.
2. Ask the server manager to store the card in the binder for the DECserver 250 software documentation set.

3.9 After Exiting DSVCONFIG

After you complete the configuration procedure, verify the load host installation. See Chapter 4 for details of this procedure.

4 Verifying the Installation

To complete the software installation, you need to perform two verifications. First, verify the load host installation by down-line loading the server image. Then, after loading the server, verify the server system installation. Here, **system installation** means the installation of the complete server system—the hardware unit with the correct software loaded and running. You verify the server system by testing a few server commands at an interactive terminal, which must be connected to the server on port 1. Printers can be tested by using the TEST PORT command on the DECserver 250.

4.1 Verifying the Load Host Installation

To verify the installation of the load host, use it to down-line load the server image to one DECserver 250 unit; then, read the DECnet event-logging messages. The messages confirm that the new load host:

- Has the appropriate files in the correct directory
- Has a correct entry in its node database for the server
- Can successfully down-line load the server image to the server

Even though there are several ways to down-line load the server image, use the NCP LOAD NODE command to verify the installation, as explained later in this section. This is the only method that tests the installation of the software from a specific load host. The LOAD NODE command lets you specify the load host, ensuring that the load host doing the down-line load is your VMS system. (A discussion of all the ways to down-line load appears in the *DECserver 250 Management Guide*.)

You can down-line load the new server image to a new server or to an existing server that is currently operating on the network. Each situation has its own requirements, as explained in the following sections.

4.1.1 If You Are Loading a New Server

A new server has no operating software in it until the initial down-line load, which occurs automatically upon server start-up. When the hardware installer powers up a unit, the server automatically requests a load of its image from any available load host. An established load host recognizes the request and down-line loads the server image.

The hardware installer can then verify the hardware installation by checking the appropriate diagnostic lights (LEDs) on the DECserver hardware unit. However, if the server image cannot be properly down-line loaded when the server is powered up, the LEDs on the server hardware unit will indicate server errors. Therefore, your coordination with the server hardware installer is important. Complete the entire software installation procedure before the hardware is powered up for the first time.

Note that this automatic down-line load verifies the hardware, but it is not sufficient for verifying the load host installation.

4.1.2 If You Are Loading an Existing Server

When an operating server is loaded, all sessions with service nodes are disconnected. Therefore, if an existing server is about to be loaded with a new image, your coordination with the server manager is important. Digital Equipment Corporation recommends that you talk with the server manager and the system manager about the needs of their users. It may be best to delay the verification of the installation and to down-line load during off-hours.

Ask the server manager of an existing server to alert the interactive users on the server of the shutdown for reloading. The server manager should have at least 30 minutes notice to disable connections and queuing to local services of the server, if necessary. (The *DECserver 250 Management Guide* discusses shutting down the server.)

4.1.2.1 Loading During Off-Hours

To be least disruptive to the users affected by the server, you and the server manager can perform the down-line load during off-hours . To do so, you can put the LOAD command in a batch job and run it at night.

4.1.3 Down-Line Loading with the LOAD Command

Down-line loading the server image for load host verification involves three steps:

1. Follow the steps listed in the next section ("Preparing for the LOAD Command").
2. Issue the LOAD command.
3. Read the event-logging message that reports the down-line load.

4.1.3.1 Preparing for the LOAD Command

To prepare for down-line loading:

1. Check the DECnet node name or DECnet node address of the server. To execute the LOAD command, you need to know one of these node identifiers. If you do not remember this information from running the DSVCONFIG procedure (see Chapter 3), run the procedure again and select the List option from the menu. The List option displays the DECnet node name and DECnet node address of all the servers you defined in this load host's node database.
2. Ask the server manager for the server's DECnet service password if there is one (the server manager may know it as the "maintenance password"). For a previously configured server, you may need to specify this password on the LOAD NODE command line.
3. Enable DECnet event logging. Event-logging messages are generated by the Network Control Program (NCP). Enter these commands:

```
$ MCR NCP RET
NCP> SET LOGGING CONSOLE EVENT 0.3,7 RET
NCP> SET LOGGING CONSOLE STATE ON RET
NCP> SET LOGGING MONITOR STATE ON RET
```

DECnet uses the Operator Communication (OPCOM) facility to display event messages on the operator's console. Make sure OPCOM is running on your host. The DCL SHOW SYSTEM command displays the status of all processes on your system. If OPCOM is not running, start it with the following command:

```
$@SYS$SYSTEM:STARTUP OPCOM RET
```

NOTE

All the other commands needed for down-line loading are part of DSVCONFIG and are executed when you run that procedure (see Chapter 3). In addition, SERVICE must be enabled on the service circuit, which is also performed by DSVCONFIG.

4.1.3.2 Issuing the LOAD Command

After warning interactive users of an operating server and after enabling event logging, you are ready to load the server. Issue the LOAD NODE command at a terminal connected to your VMS load host. On the command line, enter either the DECnet node name or the DECnet node number. The following example loads an existing server named BEETHO, with a node address of 28.1002.

```
$ MCR NCP RET
NCP> LOAD NODE BEETHO RET
```

or

```
NCP> LOAD NODE 28.1002 RET
```

If the server manager previously set a server maintenance password, you have to include the SERVICE PASSWORD keywords and specify this password as the DECnet service password on the command line. For example:

```
NCP> LOAD NODE BEETHO SERVICE PASSWORD 0F23 RET
```

To exit from NCP, type EXIT:

```
NCP>EXIT RET
$
```

4.1.3.3 Using DECnet Event Logging

After you have executed the LOAD command, check the DECnet event-logging messages that report the load to confirm that it was successful. Read the event-logging messages at your system operator's console. These messages identify your VMS system as the node that generated the event.

If no errors are reported, you can assume that the down-line load was successful. You have finished verifying the new load host. See Appendix C for an example of DECnet event logging after a successful down-line load.

If you do see errors on the event-logging messages, contact the server hardware installer. Check that the hardware is working satisfactorily. If it is, the problem is probably with the load host. Check your node database, especially the Ethernet address you entered when you defined the test server. Check that the server image is in the appropriate directory. Check that DECnet is running. Try the LOAD command again.

NOTE

When event logging is set up on a DECnet node, you can specify the destination (called the sink) of the messages. Digital Equipment Corporation suggests that you set up one DECnet sink node to receive all the logging events associated with down-line loading. In this way, all load request status information is available at one node.

4.2 Verifying the Server System Installation

To verify the total server system installation, test a few server commands at an interactive terminal connected to port 1, the console port. This step confirms that:

- The correct version of the software is in the server.
- The server hardware operates with the new software.
- The new software is running successfully.

Follow this sequence:

1 Press the RETURN key two or more times.

The following message and prompt should appear. The second line displayed ("Phil's Server") is the server's identification defined by the server manager.

```
RET
RET

DECserver 250 Server for Printers V1.0 (BL29.1) - LAT V5.1
Phil's Server

Please type HELP if you need assistance

Enter username>
```

NOTE

Be sure that the software version number and base-level number (BL*nn*) match those shown here; otherwise, you might be running old software.

2 Read the identification message to ensure that the correct version of the server image was down-line loaded. If you fail to receive this display, the problem could be:

- With the load host
- With the terminal
- With the software (incorrect software was down-line loaded

3 Enter your user name (any string of 1 through 16 characters that identifies you) and press the RETURN key. The port should now enter local mode, where the local prompt (Local>) appears:

```
Enter username> SWINSTALLER RET

Local>
```

4 Use the TEST PORT command, which verifies whether the terminal is receiving valid character data. On the command line specify the number of lines and the number of columns you want displayed. For example, this command displays 5 lines of 80 characters each:

```
Local> TEST PORT COUNT 5 WIDTH 80 RET
```

Note that you can interrupt this test by pressing any key. Appendix C shows an example of a TEST PORT display.

5 Issue the SHOW PORT command to display the characteristics of port 1:

```
Local> SHOW PORT RET>
```

A port-characteristics display should appear. Appendix C shows an example of a port-characteristics display.

6 Use the SHOW SERVICES command to show what services are available to you. The following server command produces a list of services and service announcements:

```
Local> SHOW SERVICES RET
```

Appendix C shows an example of a SHOW SERVICES display.

7 Select an available service that you are authorized to use. Use the CONNECT command to verify that the server can logically connect your device to that service. On the command line, specify the service name to which you want to connect. The following example connects your terminal to a VMS system, named SYSTEM:

```
Local> CONNECT SYSTEM RET
```

When the server successfully connects your terminal to the service specified, you no longer see the local prompt; rather, you are communicating with the service (in this example, your own VMS system).

8 Log in to the system and enter several commands to verify the ability of the server to exchange data with the service. In this case, you could enter LOGIN, SHOW TIME, and SHOW USERS.

9 Press the BREAK key or log out from the service to return to local mode. Note that pressing the BREAK key does not end the service session you started.

10 Log out the terminal from the server:

```
Local> LOGOUT RET
```

If the server system verification encounters any problem, see the server manager.

If you complete the above steps successfully, the test server is operating correctly, and you can report the successful load host installation and the server system installation to the server manager. If this installation is a software upgrade, either you or the server manager must now reload all existing servers.

4.3 Determining and Reporting Problems

If an error occurs while the DECserver 250 is being used, and you believe the error is caused by a problem with the DECserver 250 hardware or software, take one of the following actions:

- Consult the *DECserver 250 Problem Determination Guide* that came with your DECserver 250 and take the appropriate actions as outlined in the guide; the error may be user correctable.
- If you have a BASIC System Support or DECsystem Support Agreement, you should call your Digital Customer Support Center. With these services, you receive telephone support that provides high-level advisory and remedial assistance for both the hardware and software. On-site hardware support will be provided, if required. Access to Digital Equipment Corporation's Software Information Network (DSIN) is also provided.
- If you purchased the DECserver 250 within the past (1) year, and you think the problem is caused by a software error, you can submit an SPR. If you feel the problem is the hardware, return the DECserver 250 to your local Digital Servicenter for repair.

If you find an error in the DECserver 250 Documentation, you should fill out and submit the Reader's Comments form at the back of the document in which the error occurred. Include the section and page number where the error occurred.

A DECserver 250 Distribution Files

These are the DECserver 250 distribution files:

File Name	Description
KITINSTAL.COM	Command file that VMSINSTAL uses to do part of the installation procedure. This file is temporary; it is not left on the system after the installation completes
DSVCONFIG.COM	Configuration procedure
DSVCONFIG.DAT	Data file to be used by DSVCONFIG.COM
DS25_*nnn*_DEFAULTS.COM	Command procedure to be executed in conjunction with the Terminal Server Manager (TSM)
DS25*nnn*.RELEASE_NOTES (*nnn*=version number)	Release notes
DP0601ENG.SYS	DECserver 250 software image

B Using the Remote Console Facility

The DECserver 250 unit supports the VMS Remote Console Facility (RCF). This appendix explains how to use RCF from a VMS host. If you issue the BROADCAST command yourself to warn users of an upcoming down-line load, you may want to use RCF.

To connect to the server with RCF, use the CONNECT NODE command. On the command line, specify either the DECnet node name or DECnet node address of the server. This example shows a connection to the server named BEETHO:

```
$ MCR NCP   RET
NCP> CONNECT NODE BEETHO SERVICE PASSWORD 0F23  RET
Console connected (press CTRL/D when finished)
```

or

```
NCP> CONNECT NODE 28.1002 SERVICE PASSWORD 0F23  RET
Console connected (press CTRL/D when finished)
```

Press the RETURN key to start the login sequence for the remote console. Log-in password protection is enabled for the DECserver 250 remote console port. Therefore, you must supply the login password when the server prompts you with a pound sign (#) as shown below (an audible beep signal accompanies the prompt). The default password is ACCESS.

#

The prompt indicates that the link to the server has been made. After you enter the correct password, you can begin using DECserver 250 commands.

You can also use the CONNECT command with the server's Ethernet address. The following example shows a connection from a VMS system with the service circuit-ID UNA-0 to a server with the Ethernet address 08-00-2B-04-AA-2B:

```
NCP> CONNECT VIA UNA-0 PHYSICAL ADD 08-00-2B-04-AA-2B  RET
```

You may have to specify the service password with the CONNECT command if a maintenance password is specified on the server. To do so, include the SERVICE PASSWORD keywords on your command line and specify the password.

To exit from RCF, type CTRL/D:

```
Local> <CTRL/D> RET
```

To exit from NCP, type EXIT:

```
NCP> EXIT RET
$
```

NOTE

If you log out from the server with a LOGOUT command, the port is logged out but the remote console session remains active. Type CTRL/D to exit the remote console session.

The service node prompt reappears, and control passes back to NCP on your VMS system. See the *DECserver 250 Management Guide* for detailed information on RCF.

C Examples: Installation, Configuration, Verification

This appendix shows examples of the installation and the configuration procedures. It also shows the verification of a load host installation by down-line loading and reading DECnet event-logging messages. Finally, Appendix C shows the verification of a server system installation by testing server commands.

C.1 Example of an Installation

The following example shows a successful installation procedure onto a VMS V5.2 system. (In this example, server software version numbers are not supplied.)

This example also shows the procedure as Digital Equipment Corporation suggests you run it:

1. Use the option that prints the release notes.
2. Print the release notes.
3. Stop the procedure to read them.
4. Rerun the procedure.

```
 Welcome to VAX/VMS V5.2

Username: SYSTEM
Password:
 Welcome to VAX/VMS version V5.2 on node NORMS2
    Last interactive login on Monday, 19-JUN-1989 15:06
    Last non-interactive login on Monday, 26-JUN-1989 12:14
     You have 1 new Mail message.

$ SET DEF SYS$UPDATE
$
$ @VMSINSTAL  DS25  MUA0:  OPTIONS N

 VAX/VMS Software Product Installation Procedure V5.2

It is 28-JUN-1989 at 10:36.

Enter a question mark (?) at any time for help.
```

```
%VMSINSTAL-W-ACTIVE, The following processes are still active:
 ROTHWELL
 _WTA2:
* Do you want to continue anyway [NO]? YES
* Are you satisfied with the backup of your system disk [YES]? YES

Please mount the first volume of the set on  MUA0:.
* Are you ready? YES
%MOUNT-I-MOUNTED, DS25 mounted on _NORMS2$MUA0:

The following products will be processed:

  DS25 V1.0


 Beginning installation of DS25 V1.0 at 10:39

%VMSINSTAL-I-RESTORE, Restoring product saveset A ...

    Release notes included with this kit are always copied to SYS$HELP.

    Additional Release Notes Options:

 1.  Display release notes
 2.  Print release notes
 3.  Both 1 and 2
 4.  None of the above

* Select option [2]: 4
* Do you want to continue the installation [NO]?
%VMSINSTAL-I-RELMOVED , The product's release notes have been successfully
moved to SYS$HELP.

 VMSINSTAL procedure done at 10:40

$
```

Read the release notes. Run VMSINSTAL again.

```
$ @VMSINSTAL  DS25  MUA0:
 VAX/VMS Software Product Installation Procedure V5.2


It is 28-JUN-1989 at 10:41.

Enter a question mark (?) at any time for help.

%VMSINSTAL-W-ACTIVE, The following processes are still active:
 ROTHWELL
 _WTA2:
* Do you want to continue anyway [NO]? YES
* Are you satisfied with the backup of your system disk [YES]? YES

Please mount the first volume of the set on  MUA0:.
* Are you ready? YES
%MOUNT-I-MOUNTED, DS25 mounted on _NORMS2$MUA0:
The following products will be processed:

  DS25 V1.0


 Beginning installation of DS25 V1.0 at 10:43

%VMSINSTAL-I-RESTORE, Restoring product saveset A ...
%VMSINSTAL-I-RELMOVED , The product's release notes have been successfully
moved to SYS$HELP.
* Do you want to run the IVP after the installation [YES]? YES
%VMSINSTAL-I-RESTORE, Restoring product saveset B ...

Your installation is now complete.  After exiting from VMSINSTAL:
```

```
1. Edit your system start-up file so that it defines the logical
   MOM$LOAD as a search string with a value equal to the current search
   string, plus the added element SYS$SYSROOT:[DECSERVER].  For example:

   DEFINE/SYSTEM/EXEC/NAME_ATTRIBUTE=NO_ALIAS/NOLOG -
   MOM$LOAD 'current-search-string',SYS$SYSROOT:[DECSERVER]

   If the current search string associated with MOM$LOAD in your
   start-up file is SYS$SYSROOT:[DECSERVER] or if you have
   already made this change for a previous installation, there
   is no need to edit this file.

   This command ensures that the location of the server image
   is defined each time the system is rebooted, neccessary for
   successful down-line loading.

2. Configure the server into  your  host's database.
   Execute a command procedure  called  DSVCONFIG.COM. This
   command  procedure is in the SYS$SYSROOT:[DECSERVER] directory.
   If  you  have  already  executed  this  procedure from previous
   installations, you need to configure only any additional units.
   All previously defined units will still be configured.

3. The Installation Verification Procedure (IVP) for the DECserver 250
   can be found in SYS$TEST and may be run at any time by executing
   the command procedure DS25$IVP.COM.

%VMSINSTAL-I-MOVEFILES, Files will now be moved to their target directories...

Beginning installation verification procedure for DECserver 250 V1.0.

Successfully located SYS$COMMON:[DECSERVER] directory
Successfully located SYS$COMMON:[SYSHLP]DS25010.RELEASE_NOTES
Successfully located SYS$COMMON:[DECSERVER]DP0601ENG.SYS
Successfully located SYS$COMMON:[DECSERVER]DSVCONFIG.COM
Successfully located SYS$COMMON:[DECSERVER]DSVCONFIG.DAT
Successfully located SYS$COMMON:[DECSERVER]DS25_010_DEFAULTS.COM

Installation verification procecure for DECserver 250 V1.0 successful.

 Installation of DS25 V1.0 completed at 10:45


 VMSINSTAL procedure done at 10:46

$
```

Read the release notes. Run VMSINSTAL again.

C.2 Example of a Configuration: Starting DSVCONFIG.COM

The following example shows the beginning of the configuration procedure. This example assumes that the latest version of DSVCONFIG has already been run so that the DSVCONFIG.DAT file exists in the correct format. (See Chapter 3 for the prompts that are displayed if the procedure has to either create DSVCONFIG.DAT or reformat it.)

```
$ SET DEFAULT MOM$LOAD RET
$ @DSVCONFIG RET

You must assign a unique DECnet node name and DECnet node address
for each DECserver you are going to configure.

Press <RET> to start, or <CTRL/Z> to exit... RET

               DECserver Configuration Procedure

                       Menu of Options
```

C.3 Example of a Configuration: The DSVCONFIG.COM Menu

This example shows the DSVCONFIG Menu.

```
                  DECserver Configuration Procedure

                          Menu of Options
                     1 - List known DECservers
                     2 - Add a DECserver
                     3 - Swap an existing DECserver
                     4 - Delete an existing DECserver
                     5 - Restore existing DECservers
                  CTRL/Z - Exit from this procedure

     Your selection?
```

C.4 Example of a Configuration: Listing Known DECservers (Option #1)

This section and the following ones show how the configuration procedure continues for each option. With the exception of List, each option ends by automatically returning you to the menu.

```
    Your selection? 1 RET

DECnet  DECnet Server Service
Address Name   Type   Circuit Ethernet Address  Load File     Dump File
------- ------ ------ ------- ----------------- ------------- -------------
28.1001 BACH   DS250  UNA-0   08-00-2B-02-24-CC DP0601ENG.SYS DP2BACH.DMP
28.1003 MOZART DS100  UNA-0   08-00-2B-02-24-DD PS0801ENG.SYS PSDMP24DD.SYS
28.1005 HAYDN  DS200  UNA-1   08-00-2B-03-AA-F1 PR0801ENG.SYS DS2HAYDN.DMP

Total of 3 DECservers defined.
```

C.5 Example of a Configuration: Adding a DECserver (Option #2)

This example adds a new DECserver 250 unit named BEETHO.

```
         Your selection? 2 RET

Type a ? at any time for help on a question.
Type CTRL/Z for any question to return to the menu without adding the unit.

DECserver type? DS250 RET
DECnet node name for unit? BEETHO RET
DECnet node address for unit? 28.1002 RET
Ethernet address of unit? 08-00-2B-03-AA-2B RET
DECnet Service Circuit-ID? [UNA-0] RET

   If you get an error message now, the new unit won't be added,
   and you should delete it from the directory.
```

If you use the List option to get a listing of servers, you see that BEETHO appears on the listing of entries.

C.6 Example of a Configuration: Swapping an Old Unit for a New Unit (Option #3)

In this example, replace an existing DECserver 100 unit named MOZART for a new DECserver 250 unit with the same DECnet node name. The new DECserver 250 has printer support for both parallel and serial printers. The DECnet node address always stays the same with Swap. The new server also has the same service circuit-ID as the old server. (If you use Swap to change the characteristics of the same server, you have to specify the Ethernet address even though it will not change.)

```
Your selection? 3 RET

Type a ? at any time for help on a question.
Type CTRL/Z for any question to return to the menu without changing the unit.

What is the DECnet node name you want to swap? MOZART RET
DECserver at Ethernet address 08-00-2B-02-24-DD is being modified.

Enter the new Ethernet address, and any other DECnet
characteristics you want to modify.

DECserver type? [DS100] DS250 RET
DECnet node name for unit? [MOZART] RET
Ethernet address of unit? 08-00-2B-03-AA-AB RET
DECnet Service Circuit-ID? [UNA-0] RET
```

C.7 Example of a Configuration: Deleting a DECserver from the Database (Option #4)

This example shows the deletion from the load host's node database of the existing server with the DECnet node name BACH.

```
        Your selection? 4 RET

(Press CTRL/Z to return to menu.)
Enter the DECnet node name of the server you want to delete? BACH RET
%NCP-I-NMLRSP, listener response - Success
Remote node = 28.1001 (BACH)
%NCP-I-RECDELET, Database entry deleted
```

If you use the List option to get a listing of servers, you see that BACH no longer appears.

C.8 Example of a Configuration: Restoring Existing DECservers to the Database (Option #5)

This example shows the restoration of the local down-line load database.

```
     Your selection? 5 RET

Restoring existing DECservers to host DECnet database...
Host DECnet database successfully restored.
```

C.9 Example of Verification: Verifying a Load Host Installation

The following example, presented in five parts, shows the installation verification for a VMS load host. This procedure tests that your VMS system can perform successfully as a down-line load host for a particular server.

In this example, the VMS system is named SYSTEM. The server that is loaded is a DECserver 250 unit with DECnet node name BEETHO. BEETHO is an existing server currently operating on the network. This example assumes that the down-line load is performed during normal working hours.

C.9.1 Using RCF and Warning Server Users

This example uses the server's default login password, ACCESS.

```
$ MCR NCP CONNECT NODE BEETHO SERVICE PASSWORD FF23 RET
Console connected (press CTRL/D when finished)
RET
# ACCESS RET (not echoed)
DECserver 250 Print Server V1.0 (BL29.1) - LAT V5.1


Please type HELP if you need assistance


Enter username >  SWINSTALLER RET

Local> SET PRIVILEGED RET
Password> password (not echoed) RET
Local > BROADCAST ALL "The server will be reloaded in 3 minutes." RET
Local> CTRL/D
$
```

C.9.2 Enabling DECnet Event Logging and Checking Server Names

```
NCP> SET LOGGING CONSOLE EVENT 0.3,7 RET
NCP> SET LOGGING CONSOLE STATE ON RET
NCP> SET LOGGING MONITOR STATE ON RET

NCP> EXIT RET

$ SET DEFAULT MOM$LOAD RET
$ @DSVCONFIG RET

You must assign a unique DECnet node name and DECnet node address
for each DECserver you are going to configure.

Press <RET> to start, or <CTRL/Z> to exit... RET

                DECserver Configuration Procedure


                        Menu of Options
                    1 - List known DECservers
                    2 - Add a DECserver
                    3 - Swap an existing DECserver
                    4 - Delete an existing DECserver
                    5 - Restore existing DECservers
                CTRL/Z - Exit from this procedure


     Your selection? 1 RET

DECnet  DECnet Server Service
Address Name   Type   Circuit Ethernet Address  Load File     Dump File
------- ------ ------ ------- ----------------- ------------- -------------

28.1002 BEETHO DS250  UNA-0   08-00-2B-03-AA-2B DP0601ENG.SYS DP2BEETHO.DMP

Total of 1 DECserver defined.

                DECserver Configuration Procedure

                        Menu of Options
                    1 - List known DECservers
                    2 - Add a DECserver
                    3 - Swap an existing DECserver
                    4 - Delete an existing DECserver
                    5 - Restore existing DECservers
                CTRL/Z - Exit from this procedure

     Your selection?  CTRL/Z

$
```

C.9.3 Down-Line Loading with the LOAD Command

```
$ MCR NCP LOAD NODE BEETHO PASSWORD FF23 RET
```

C.9.4 DECnet Event-Logging Display after Issuing LOAD

```
NCP> LOAD NODE BEETHO SERVICE PASSWORD FF23 RET
DECnet event 0.3, automatic line service
From node 4.205 (SYSTEM), 14-DEC-1988 01:35:20.47
Circuit UNA-0, Load, Requested, Node = 28.1002 (BEETHO)
File = MOM$LOAD:DP0601ENG, Operating system Ethernet address = 08-00-2B-03-AA-2B

DECnet event 0.3, automatic line service
From node 4.205 (SYSTEM), 14-DEC-1988 01:43:21.14
Circuit UNA-0, Load, Successful, Node = 28.1002 (BEETHO)
File = MOM$LOAD:DP0601ENG, Operating system Ethernet address = 08-00-2B-04-AA-2B
```

C.9.5 Conclusion of a Load Host Installation Verification

```
NCP> CLEAR LOGGING CONSOLE EVENT 0.3,7 RET
NCP> EXIT RET
$
```

C.10 Example of Verification: Verifying the Server System Installation

This example shows the verification of a server system installation. This procedure tests the hardware, the correctness of the software version, and the ability of the new software to run successfully.

It assumes that:

- You are at a terminal connected to the server's Port 1.
- Your username is SWINSTALLER.
- Your user password is SQUIDS.
- You will test the server by connecting to your own VMS system, SYSTEM. The new DECserver 250 software is Version 1.0.

```
RET
RET
DECserver 250 Server for Printers V1.0 (BL29.1) - LAT V5.1

Please type HELP if you need assistance

Enter username>  SWINSTALLER RET

Local> TEST PORT COUNT 5 WIDTH 65 RET

 !"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`
!"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`a
"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`ab
#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`abc
$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`abcd

Local> SHOW PORT RET
```

The display at the port of a new DECserver 250 unit should match the following example, which contains the factory-set values except the port number and username:

```
Port 1:  SWINSTALLER

Character Size:         8       Input Speed:        9600
Flow control:         XON       Output Speed:       9600
Parity:              None       Modem Control:  Disabled

Access:              Local      Local Switch:       None
Backward Switch:      None      Name:             PORT_1
Break:               Local      Session Limit:         4
Forward Switch:       None      Type:            Soft


Preferred Service: None

Authorized Groups:   0
(Current)  Groups:   0

Enabled Characteristics:

Autobaud, Autoprompt, Broadcast, Input Flow Control, Loss Notification,
Message Codes, Output Flow Control, Verification

Local> SHOW SERVICES ALL SUMMARY RET


Service Name         Status       Identification

DEVELOP            2 Connected    Hardware Timesharing Service Ident
DOCUMENT             Available    Documentation Timesharing
TEST                 Unavailable  As usual
TIMESHARING          Unknown      Server Software Development
SYSTEM               Available    VAX/VMS 8600
```

```
Local> CONNECT SYSTEM RET
Local -010- Session 1 to SYSTEM established

        SYSTEM -- VAX 8600, The Best for Down-line Loading

Username: SWINSTALLER RET
Password: SQUIDS RET (not echoed)

        Welcome to VAX/VMS version V5.2 on node SYSTEM
    Last interactive login on Wednesday, 14-DEC-1988 07:25
    Last non-interactive login on Thursday, 27-MAR-1988 17:18

SYS$MANAGER:NOTICE.TXT -- SYSTEM System Notices
------------------------------------------------------------------------
------------------------------------------------------------------------

14-DEC-1988  All users, please purge your files!

$ SHOW TIME RET
  14-DEC-1988 07:00:09
$ SHOW USERS RET
          VAX/VMS Interactive Users         14-DEC-1988 07:00:13.13
    Total number of interactive users =   4
 Username     Process Name      PID     Terminal
 DAISY        DAISY           20A0257A  VTA3341        LTA3341:
 HEATHER      HEATHER         20A02217  VTA3391        LTA3391:
 IVY          IVY             20A020D2  VTA3234        Disconnected
 ROSE         ROSE            20A02321  VTA3471        LTA3471:
 SWINSTALLER  SWINSTALLER     20A02001  VTA3471        LTA3511:

$ LOGOUT RET
  SWINSTALLER    logged out at 14-DEC-1988 07:00:20.98
Local -011- Session 1 disconnected from SYSTEM

Local> LOGOUT RET
Local -020- Logged out port 1
```

D How to Order Documents

D.1 Introduction

All the information you need to order additional documents is provided here. The ordering procedure you use depends on:

- Whether you are a customer or a Digital employee
- Your location: USA or Puerto Rico, Canada, or other
- Your means of placing the order: telephone, electronic mail, or regular mail

The specific ordering procedures and the order numbers for software and hardware manuals are provided in the following sections.

D.2 Order Numbers

For software manuals, use the documentation kit order number. For hardware manuals, use the document order number. There are software documentation kits for these operating systems: VMS and ULTRIX-32.

D.2.1 VMS Software Documentation Kit

The VMS documentation kit order number is QA-VTMAA-GZ. Each kit contains the following manuals:

- *DECserver 250 Management Guide*
- *Terminal Server User's Reference Card*
- *DECserver 250 Software Installation Guide (VMS)*
- *Terminal Server Commands and Messages Reference*
- *DECserver 250 Commands Mini-Reference*
- *DECserver 250 Problem Determination Guide*

D.2.2 ULTRIX-32 Software Documentation Kit

The ULTRIX-32 software documentation kit order number is QA-VTNAA-GZ. This kit has the same manuals as the VMS documentation kit with one exception: it contains the *DECserver 250 Software Installation Guide (ULTRIX-32)* instead of the VMS version.

D.2.3 TSM Documentation Kit

The TSM documentation kit order number is QLZ42–GZ. This kit is intended for the installer and manager of the TSM software product and contains two manuals:

- *Guide to Terminal Server Manager*
- *Terminal Server Manager Software Installation Guide*

D.2.4 Hardware Documents

The order numbers for the hardware manuals are listed in Table D-1.

Table D–1 Hardware Documents

Manual Title	Order Number
DECserver 250 Hardware Installation/Owner's Guide	EK-D250C-IN
DECserver 250 Identification Card	EK-D250T-ID
DECserver 200 Rackmount Option Installation Guide	EK-DC200-IN

D.3 Ordering Procedures for Customers

If you are a customer, refer to Tables D-2 and D-3 for ordering information.

Table D–2 How to Order By Telephone

If You Live In	Call
New Hampshire, Alaska, or Hawaii	(603) 884-6660
Continental USA and Puerto Rico	(800) 258-1710
Canada	(800) 267-6146

Table D–3 How to Order By Mail

If You Live In	Write To
USA or Puerto Rico[1]	Digital Equipment Corporation, P.O. Box CS2008, Nashua, New Hampshire 03061
Canada	Digital Equipment of Canada LTD., 940 Belfast Road, Ottawa, Ontario, Canada K1G 4C2 Attn: A&SG Business Manager
Other	Digital Equipment Corporation, A&SG Business Manager, c/o local Digital subsidiary or approved distributor

[1]Any prepaid order from Puerto Rico must be placed with the local Digital subsidiary: (809) 754-7575

D.4 Ordering Procedures for Digital Employees

D.4.1 Software Documentation Kits

If you are a Digital employee, use the "Internal Software Order Form" to order software documentation kits. The form is available from office services and the Software Distribution Center (SDC). Complete the form according to instructions and mail it.

D.4.2 Hardware Manuals

If you are a Digital employee, you can place your order for hardware manuals by telephone, VAXmail, or DECmail as follows:

- Telephone number: (617) 351-4323 (DTN: 234-4323)
- DECmail address: ORDER @NRO
- VAXmail address: PUFFIN::MCNEIL

Note

If you use electronic MAIL, DECmail is preferred over VAXmail.

Index

A

Alternate load hosts
  installing distribution software onto • 2–10
  recommendation • 1–3
  using • 2–10, 2–11, 2–12
Areas • 3–5

B

BROADCAST command • C–7
  using RCF to issue • B–1

C

CLEAR LOGGING CONSOLE EVENT
    command • C–9
Command procedures
  DSVCONFIG.COM • 1–5, 3–3, 3–10, C–4
  VMSINSTAL.COM • 1–4, 2–1, 2–2
Commands
  see specific commands
Configuration • 1–5, 3–1
  definition of • 1–5, 3–1
  example of • C–4
    Add option • C–5
    Delete option • C–6
    DSVCONFIG.COM menu • C–4
    List option • C–5
    Restore option • C–7
    Swap option • C–6
  options • 3–3
  preparing for • 3–8
  procedure
    see DSVCONFIG.COM
  running DSVCONFIG.COM
    see DSVCONFIG.COM
  with VAXclusters • 1–5, 2–12, 3–3, 3–11, 3–16, 3–17
CONNECT command • 4–7, B–1, C–7, C–11
Connections
  from RS-232-C ports • 1–1
  of printers to server
    of terminal to server • 1–1
Conventions
  of DSVCONFIG.COM • 3–9
  of VMSINSTAL.COM • 2–2
Coordinating
  with server hardware installer • 4–2, 4–5
  with server manager • 4–2, 4–8

D

Databases
  affected by DSVCONFIG • 3–3
  keeping synchronized • 3–3, 3–14
DECnet • 1–3, 3–8
DECnet characteristics
  specifying during DSVCONFIG • 3–4
DECnet database • 3–4
DECnet error messages • 3–10, 3–14
DECnet event logging
  see Event logging
DECnet load database • 3–3, 3–14, 3–15
DECnet node address
  description • 3–13
  ensuring uniqueness • 3–9
  specifying during DSVCONFIG • 3–5
  with areas • 3–5
DECnet node name
  description • 3–13
  ensuring uniqueness • 3–9
  specifying during DSVCONFIG • 3–5
DECnet Phase IV
  see DECnet
DECserver 100 unit • 2–10, 3–1
DECserver 200 unit • 2–10, 3–1
DECserver 250 Identification Card • 3–4, 3–9, 3–18

DECserver 250 unit • 2–10, 3–1
  features of • 1–1
DECserver 500 unit • 2–10, 3–1
Disk space requirements • 1–3, 2–1
Distribution software
  disk space required • 1–3, 2–1
  file names • A–1
  in distribution kit • 1–1
Down-line loading • 1–6
  confirming with event logging • 4–5
  disk space required • 1–3, 2–1
  during off hours • 4–2
  for verification • 4–1
  image file • 3–6
  load file name • A–1
  preparing for • 4–3
  to existing server • 4–2
  to new server • 4–2
  upon server start-up • 4–2
  with LOAD command • 4–1
    issuing LOAD • 4–2, 4–4
DSVCONFIG.COM • 1–5, 3–10, A–1, C–4
  different versions of • 2–10, 3–1
  example of • C–4
    Add option • C–5
    Delete option • C–6
    DSVCONFIG.COM menu • C–4
    List option • C–5
    Restore option • C–7
    Swap option • C–6
  exiting from • 3–11
  options
    adding • 3–13
    listing servers • 3–12
    restoring • 3–15
  preparing for • 3–8
  requirements
    conventions • 3–9
  restoring local database with • 3–15
  running the procedure • 3–10, C–4
  using for DECserver 100 units • 2–10, 3–1
  using for DECserver 200 units • 2–10, 3–1
  using for DECserver 250 units • 2–10, 3–1
  using for DECserver 500 units • 2–10, 3–1
DSVCONFIG.DAT • 1–5, 3–1
  contents of • 3–12
Dump file • 3–6
Dump file name
  specifying during DSVCONFIG • 3–6

E

Error messages • 3–10, 3–14
Ethernet • 1–2
Ethernet address
  specifying during DSVCONFIG • 3–5
Ethernet circuit • 3–6
Event logging • 4–1, 4–3
  disabling • C–9
  enabling • 4–3
    example of • C–8
  example of • C–9
  reading the messages • C–9
  using to verify a down-line load • 4–5

H

Hosts, *see* Load hosts
Hardware • 1–1, 4–1, 4–2, 4–5

I

Image file • 1–3
Installation • 1–3, 2–10, 2–11
  disk space required • 1–3, 2–1
  example of • C–1
  onto alternate load hosts • 2–10, 2–12
  onto other operating systems • 2–12
  onto VAXclusters • 1–3, 2–12
  preparing for • 2–1
  procedure
    see VMSINSTAL.COM
  running VMSINSTAL.COM
    see VMSINSTAL.COM
  verifying • 1–6, 4–1

L

LAN • 1–1
LAT • 1–2
  architecture • 1–2
  protocol • 1–2
LAT Control Program
  see LATCP
LATCP • 1–2
LOAD command • 4–1, C–9
  example of • C–9
  in batch job • 4–2
  issuing • 4–4
Load file
  specifying during DSVCONFIG • 3–6
Load host database
  see Node database
Load hosts • 1–3
  alternates • 1–3
  disk space requirements • 1–3, 2–1
  prerequisites • 1–3
  recommended number • 1–3
  VAXclusters as • 1–3, 1–5, 2–12, 3–3, 3–16, 3–17
Loading
  see Down-line loading
Local Area Network
  see LAN
Local Area Transport
  see LAT
LOGOUT command • 4–8
LTDRIVER • 1–2

M

MOM$LOAD • 2–8, 3–10

N

NCP • 3–3, 4–3, 4–4
NCP commands
  see specific commands
Node database • 1–3, 1–5, 3–1, 3–3, 3–12, 3–14, 3–15
  definition of • 3–3
Nodes • 1–1
  as load hosts • 1–3
  divided into areas • 3–5

O

OPCOM • 4–4
Operator Communication facility
  (see) OPCOM

P

Passwords
  server maintenance password • 4–3, 4–4, B–1, B–2
  service password (DECnet service password) • 4–3, 4–4, B–1, B–2
Preparation
  for configuring the node database • 3–8
  for down-line loading • 4–3
  for installing the distribution software • 2–1
  for running the configuration procedure • 3–8
  for running the installation procedure • 2–1
Protection, of server image • 4–4
Protocol • 1–2

R

RCF
  connecting to node • B–1
  disconnecting from node • B–2
  using to issue BROADCAST • B–1
Release notes • 1–4, 2–4, 2–12
  directory in • 2–5
  file name • A–1

Release notes (cont'd)
printing • 2–1, 2–2, 2–4, 2–5, C–1
Remote Console Facility
see RCF
Restoring local database
with DSVCONFIG.COM • 3–15
with RESTORE parameter • 3–15
with VAXclusters • 3–16
RS-232-C connections • 1–1
Running DSVCONFIG.COM • 3–10, C–4
Running VMSINSTAL.COM • 2–2
on VMS V5.2 and later • C–1

S

Savesets • 2–3
Server
see DECserver 250 unit
Server configuration database • 1–5, 3–1
Server dump file • 3–6
Server image • 1–3
see also Down-line loading
description • 1–5
file name • 3–6
Server name • 3–5
Server software
see Distribution software
see Server image
Server type
specifying during DSVCONFIG • 3–6
Service circuit • 3–12, 3–13, 3–14
specifying during DSVCONFIG • 3–6
SERVICE enabled • 4–4
Service nodes • 1–2
prerequisites • 1–2
Services • 1–2
SET LOGGING CONSOLE EVENT command • 4–3, C–8
SET LOGGING CONSOLE STATE command • 4–3, C–8
SET LOGGING MONITOR STATE command • 4–3, C–8
SHOW NODE command • 3–9
SHOW PORT command • 4–7, C–10
SHOW SERVICES command • 4–7, C–10
Synchronizing databases • 3–3, 3–14
on VAXcluster nodes • 3–3

T

Terminal Server Manager (TSM) • 1–4, A–1
TEST PORT command • 4–7, C–10
Testing server commands
for verification • 4–1

U

Up-line dumping • 3–6
disk space required • 1–3, 2–1
dump file name • 3–6
received by load host • 1–3, 2–10

V

VAXclusters
as alternative load host • 2–12
as load host • 1–3, 1–5, 2–12, 3–3, 3–16, 3–17
installing distribution software onto • 2–7, 2–12
restoring local database • 3–16
VAX/VMS
and LAT • 1–2
Verifying the installation • 1–3, 1–6
of load host • 1–6, 1–7, 4–1, 4–3
by down-line loading • 1–7, 4–1, 4–3
by using DECnet event logging • 4–5
example of • C–7
conclusion • C–9
disabling event logging • C–9
down-line loading • C–9
event logging • C–9
LOAD command • C–9
using DECnet event logging • C–8
using RCF • C–7
warning server users • C–7
of server system • 1–6, 1–7, 4–1

Verifying the installation
of server system (cont'd)
by using server commands • 1–7, 4–5
example of • C–9
VMSINSTAL.COM • 1–4, 2–1, 2–2
conventions • 2–2
example of • C–1
preparing for • 2–1
printing release notes • 2–1, 2–2, 2–4, 2–5, C–1
running the procedure • 2–2
on VMS V5.2 and later • C–1